

For model number coding, see **A2-136**.

¹ Distance between the mechanical stopper and the stroke starting position.

¹ Indicates a value when two inner blocks are in close contact with each other.