



Guide Ball Bushing/Linear Bushing

THK General Catalog

Guide Ball Bushing/Linear Bushing

THK General Catalog

A Product Descriptions

Features and Types	A4-4
Features of the Guide Ball Bushing	A4-4
• Structure and Features	A4-4
• Examples of Changing the Linear Bushing to the Guide Ball Bushing ..	A4-6
Types of the Guide Ball Bushing	A4-7
• Types and Features	A4-7
Point of Selection	A4-8
Flowchart for Selecting a Guide Ball Bushing ..	A4-8
• Steps for Selecting a Guide Ball Bushing ..	A4-8
Rated Load and Nominal Life	A4-9
Table of Equivalent Factors	A4-13
Precautions To Be Taken if an Eccentric Load Is Applied ..	A4-13
Accuracy Standards	A4-13

Dimensional Drawing, Dimensional Table

Model LG	A4-14
----------------	-------

Point of Design

Assembling the Guide Ball Bushing	A4-16
---	-------

Options

Lubrication	A4-19
Dust prevention	A4-19

Model No.

• Model Number Coding	A4-20
-----------------------------	-------

Precautions on Use

Features and Types

Features of the Linear Bushing	A4-23
• Structure and Features	A4-23
Types of the Linear Ball Bushing	A4-24
• Types and Features	A4-24
Classification Table	A4-34

Point of Selection

Flowchart for Selecting a Linear Bushing ..	A4-36
• Steps for Selecting a Linear Bushing	A4-36
Rated Load and Nominal Life	A4-37
Table of Equivalent Factors	A4-41
Precautions To Be Taken if an Eccentric Load Is Applied ..	A4-41
Accuracy Standards	A4-41

Dimensional Drawing, Dimensional Table

Model LM	A4-42
Model LM-GA (Metal Retainer Type)	A4-44
Model LM-MG (Stainless Steel Type)	A4-46

Model LME	A4-48
Model LM-L	A4-50
Model LMF	A4-52
Model LMF-M (Stainless Steel Type)	A4-54
Model LMF-L	A4-56
Model LMF-ML (Stainless Steel Type) ..	A4-58
Model LMK	A4-60
Model LMK-M (Stainless Steel Type)	A4-62
Model LMK-L	A4-64
Model LMK-ML (Stainless Steel Type) ..	A4-66
Model LMJK	A4-68
Model LMJK-L	A4-70
Model LMH	A4-72
Model LMH-M (Stainless Steel Type)	A4-74
Model LMH-L	A4-76
Model LMH-ML (Stainless Steel Type) ..	A4-78
Model LMIF	A4-80
Model LMIF-L	A4-82
Model LMCFL	A4-84
Model LMIK	A4-86
Model LMIK-L	A4-88
Model LMCK-L	A4-90
Model LMIH	A4-92
Model LMIH-L	A4-94
Model LMCH-L	A4-96
Models SC6 to 30	A4-98
Models SC35 to 50	A4-100
Model SL	A4-102
Model SH	A4-104
Model SH-L	A4-106
Model SK	A4-108
• Standard LM Shafts	A4-109
• Specially Machined Types	A4-110
• Dedicated Shafts	A4-111
• Table of Rows of Balls and Masses for Clearance-adjustable Types and Open Types of the Linear Bushing	A4-111

Point of Design

Assembling the Linear Bushing	A4-112
-------------------------------------	--------

Options

Lubrication	A4-119
Material and Surface Treatment	A4-119
Dust prevention	A4-120
Felt Seal Model FLM	A4-120

Model No.

• Model Number Coding	A4-121
-----------------------------	--------

Precautions on Use

B Support Book (Separate)

Features and Types B4-4

Features of the Guide Ball Bushing..... B4-4

- Structure and Features B4-4
- Examples of Changing the Linear Bushing to the Guide Ball Bushing .. B4-6

Types of the Guide Ball Bushing B4-7

- Types and Features B4-7

Point of Selection B4-8

Flowchart for Selecting a Guide Ball Bushing .. B4-8

- Steps for Selecting a Guide Ball Bushing .. B4-8

Rated Load and Nominal Life B4-9

Precautions To Be Taken if an Eccentric Load Is Applied .. B4-12

Mounting Procedure and Maintenance .. B4-13

Assembling the Guide Ball Bushing B4-13

Options B4-16

Lubrication B4-16

Dust prevention B4-16

Model No. B4-17

- Model Number Coding..... B4-17

Precautions on Use B4-18

Features and Types B4-20

Features of the Linear Bushing B4-20

- Structure and Features B4-20

Types of the Linear Ball Bushing B4-22

- Types and Features B4-22

Classification Table..... B4-32

Point of Selection B4-34

Flowchart for Selecting a Linear Bushing .. B4-34

- Steps for Selecting a Linear Bushing B4-34

Rated Load and Nominal Life B4-35

Precautions To Be Taken if an Eccentric Load Is Applied .. B4-38

Mounting Procedure and Maintenance .. B4-39

Assembling the Linear Bushing B4-39

Options B4-46

Lubrication B4-46

Material and Surface Treatment B4-46

Dust prevention B4-47

Felt Seal Model FLM B4-47

Model No. B4-48

- Model Number Coding..... B4-48

Precautions on Use B4-50

Features of the Guide Ball Bushing




Fig.1 Structure of the Guide Ball Bushing model LG

Structure and Features

Since model LG has 4 rows of circular arc grooves (raceways), it does not need a mechanism to prevent the outer tube from rotating. In addition, its load rating is much larger than Linear Bushing model LM with the same dimensions. Therefore, replacing the Linear Bushing with the Guide Ball Bushing will reduce the size and cost of the guide unit and extend the service life.

[Higher Load Rating than the Linear Bushing]

Since model LG ensures an R contact through the use of circular arc grooves for ball contact, it achieves a load rating more than twice that of point-contact Linear Bushing model LM with the same size.

[A Rotation Stopper is Unnecessary Because of Raceways]

Since model LG has circular arc grooves, it does not need a rotation stopper required for Linear Bushing model LM, and allows the machine design to be compact.

[Interchangeable in Dimensions with Linear Bushing Model LM]

Since the outer tube of model LG has the same outer diameter and length as that of Linear Bushing model, LM, it is possible to replace Linear Bushing model LM with Guide Ball Bushing model LG as assemblies.

[Various Combinations of Nut and Shaft are Available (Any Combination is Allowed)]

As with the Linear Bushing, any combination of the LG nut and the LG shaft of model LG is allowed.

Examples of Changing the Linear Bushing to the Guide Ball Bushing

Advantage of using the Guide Ball Bushing 1: Longer service life

Since model LG has a rated load more than 2.4 times the Linear Bushing with the same dimensions, replacing the Linear Bushing with model LG will increase the service life by more than 13.8 times.

Table1 Comparison of the service life between Guide Ball Bushing mode LG and Linear Bushing model LM

Model No.	Basic dynamic load rating: C [N]	Load rating ratio	Service life ratio
LG4S	335	3.8 times	54.8 times
LM4	88.2		
LG6S	494	2.4 times	13.8 times
LM6	206		
LG8S	796	3.0 times	27.0 times
LM8	265		

Advantage of using the Guide Ball Bushing 2: Smaller machine size

Since the Linear Bushing is not suitable for applications where a load in the rotational direction is applied, it is necessary to use two or more Linear Bushing units in parallel or have a rotation stopper mechanism even under conditions where a torque is not applied. In contrast, the Guide Ball Bushing, which has a structure containing four rows of circular arc grooves, is operable with a single shaft and therefore contributes to downsizing the machine, unless an excessive load is applied.

Achieves a load carrying capacity approximately three times the Linear Bushing in a half space




Table2 Comparison of the permissible moment between Guide Ball Bushing mode LG and Linear Bushing model LM

Model No.	Permissible moment: M_A [N·m]
One unit of LG8S is used	1.46
Two units of LM8 are used	0.45


Types of the Guide Ball Bushing

Types and Features

Model LG-S

Specification Table⇒ **A4-14**


In this type, the diameter and the length of the LG nut are the same as that of Linear Bushing model LM. This type is dimensionally interchangeable with model LM.



Model LG-L

Specification Table⇒ **A4-14**


Model LG-L is a long type in which the overall length of the LG nut is longer than that of model LG-S to increase the load carrying capacity.



Flowchart for Selecting a Guide Ball Bushing

Steps for Selecting a Guide Ball Bushing

The following flowchart should be used as a guide for selecting a Guide Ball Bushing.




Rated Load and Nominal Life

Load Rating

The rated load of the Guide Ball Bushing varies according to the position of balls in relation to the load direction. The basic load ratings indicated in the specification tables each indicate the value when one row of balls receiving a load are directly under the load.

If the Guide Ball Bushing is mounted so that two rows of balls evenly receive the load in the load direction, the rated load changes as shown in Table1.

Table1. Rated load of the Guide Ball Bushing

Rows of balls	Ball position	Load Rating
4 rows		1.41×C

Note: For specific values for "C" above, see the respective specification table.

[Calculating the Nominal Life]

The nominal life of the THK guide ball bushing is defined as 50 km. The nominal life (L_{10}) is calculated from the basic dynamic load rating (C) and the load acting on the guide ball bushing (P_c) using the following formula.

$$L_{10} = \left(\frac{C}{P_c} \right)^3 \times 50 \quad \dots\dots\dots(1)$$

L_{10} : Nominal life (km)

C : Basic dynamic load rating (N)

P_c : Calculated load (N)

*This nominal life formula may not apply if the length of the stroke is less than or equal to twice the length of the nut.

When comparing the nominal life (L_{10}), you must take into account whether the basic dynamic load rating was defined based on 50 km or 100 km. Convert the basic dynamic load rating based on ISO 14728-1 as necessary.

ISO-regulated basic dynamic load rating conversion formula:

$$C_{100} = \frac{C_{50}}{1.26}$$

C_{50} : Basic dynamic load rating based on a nominal life of 50 km

C_{100} : Basic dynamic load rating based on a nominal life of 100 km

[Calculating the Modified Nominal Life]

During use, a guide ball bushing may be subjected to vibrations and shocks as well as fluctuating loads, which are difficult to detect. In addition, the surface hardness of the raceways, the operating temperature, and having blocks arranged directly behind one another will have a decisive impact on the service life. Taking these factors into account, the modified nominal life (L_{10m}) can be calculated according to the following formula (2).

•Modified factor α

$$\alpha = \frac{f_H \cdot f_T \cdot f_c}{f_w}$$

α : Modified factor

f_H : Hardness factor (see Fig.1 on **A4-11**)

f_T : Temperature factor

f_c : Contact factor (see Table2 on **A4-12**)

f_w : Load factor (see Table 3 on **A4-12**)

•Modified nominal life L_{10m}

$$L_{10m} = \left(\alpha \times \frac{C}{P_c} \right)^3 \times 50 \quad \dots\dots\dots(2)$$

L_{10m} : Modified nominal life (km)

C : Basic dynamic load rating (N)

P_c : Calculated load (N)

● **When a Moment Load is Applied to a Single Nut or Two Nuts in Close Contact with Each Other**

When a moment load is applied to a single nut or two nuts in close contact with each other, calculate the equivalent radial load at the time the moment is applied.

$$P_u = K \cdot M$$

P_u : Equivalent radial load (N)
(with a moment applied)

K : Equivalent factors
(see Table 4 to Table 5 on **A4-13**)

M : Applied moment (N·mm)

However, " P_u " is assumed to be within the basic static load rating (C_0).

● **When a Moment Load and a Radial Load are Simultaneously Applied**

When a moment and a radial load are applied simultaneously, calculate the service life based on the sum of the radial load and the equivalent radial load.

■ **f_H : Hardness Factor**

To maximize the load capacity of the Guide Ball Bushing, the hardness of the raceways needs to be between 58 to 64 HRC.

If the hardness is lower than this range, the basic dynamic load rating and the basic static load rating decrease. Therefore, it is necessary to multiply each rating by the respective hardness factor (f_H).

Normally, $f_H = 1.0$ since the Guide Ball Bushing has sufficient hardness.




Fig. 1 Hardness Factor (f_H)

■ **f_T : Temperature Factor**

The temperature of the environment where the Guide Ball Bushing is used must be 80°C or below. Therefore, adopt a temperature factor $f_T = 1.0$.

The Guide Ball Bushing does not support high temperature. Therefore, if the environment temperature exceeds 80°C, it is necessary to use another product.

■f_c: Contact Factor

When multiple nuts are used in close contact with each other, their linear motion is affected by moments and mounting accuracy, making it difficult to achieve uniform load distribution. In such applications, multiply the basic load rating (C) and (C₀) by the corresponding contact factor in Table2.

Note) If uneven load distribution is expected in a large machine, take into account the respective contact factor indicated in Table2.

Table2 Contact Factor (f_c)

Number of nuts in close contact with each other	Contact factor f _c
2	0.81
3	0.72
4	0.66
5	0.61
Normal use	1

■f_w: Load Factor

In general, reciprocating machines tend to experience vibrations or impacts during operation, and it is extremely difficult to accurately determine the vibrations generated during high-speed operation and impacts during frequent starts and stops. Therefore, when the actual load applied to a guide ball bushing cannot be obtained, or when speed and vibrations have a significant influence, divide the basic dynamic load rating (C) by the corresponding load factor in Table 3, which has been empirically obtained.

Table 3 Load Factor (f_w)

Vibrations/ impact	Speed(V)	f _w
Faint	Very low V≤0.25m/s	1 to 1.2
Weak	Slow 0.25<V≤1m/s	1.2 to 1.5
Medium	Medium 1<V≤2m/s	1.5 to 2
Strong	High V>2m/s	2 to 3.5

[Calculating the Service Life Time]

When the nominal life (L₁₀) has been obtained, if the stroke length and the number of reciprocations per minute are constant, the service life time is obtained using the following equation.

$$L_h = \frac{L_{10} \times 10^3}{2 \times \ell_s \times n_1 \times 60}$$

- L_h

:

Service life time

(h)
- ℓ_s

:

Stroke length

(m)
- n₁

:

Number of reciprocations per minute

(min⁻¹)

Table of Equivalent Factors

Table4 Equivalent Factors of Model LG-S

Model No.	Equivalent factor: K	
	Single nut	Double blocks
LG 4S	1.062	0.193
LG 6S	0.885	0.121
LG 8S	0.708	0.096

Table5 Equivalent Factors of Model LG-L

Model No.	Equivalent factor: K
	Single nut
LG 4L	0.733
LG 6L	0.465
LG 8L	0.442

Precautions To Be Taken if an Eccentric Load Is Applied

Model LG achieves a much higher load-carrying capacity in receiving the eccentric load (moment and torque) than Linear Bushing model LM because of 4 rows of raceways. However, under conditions where the eccentric load is larger, the product may result in poor operation or early failure. In such cases, we recommend using Ball Spline model LBS or LT, both of which have larger load-carrying capacities (see **A3-52** onward for model LBS, or **A3-76** onward for model LT).

Accuracy Standards

[Guide Ball Bushing]





Table6 Run-out of the outer diameter of the nut relative to the support section of the shaft

Unit: μm

Overall shaft length (mm)		Run-out(max)*
-	200 or less	72
Above 200	250 or less	133


*: The value if the radial clearance is zero

Model LG



Model No.	Shaft Diameter D _o h7	Nut dimensions					
		Outer diameter		Length		Pin hole	
		D	Tolerance	L	Tolerance	b +0.05 0	t +0.08 -0.02
LG4S	4	8	0	12	0	1.2	0.8
LG4L		8	-0.009	19	-0.12	1.2	0.8
LG6S	6	12	0	19	0	1.5	1.2
LG6L		12		27		1.5	1.2
LG8S	8	15	-0.011	24	-0.2	2	1.5
LG8L		15		30		2	1.5

Note) The basic load ratings each indicate the value when one row of balls receiving a load are directly under the load.
The permissible torques each represent a reference value when the radial clearance is maximum (+10 μ m).
The permissible moments each indicate a reference value when the radial clearance is the maximum (+10 μ m) with one row of balls receiving a load being directly under the load.



Model number coding

① LG shaft only

LG4 -100L

Model No.

Overall LG shaft length

② LG nut only

LG4S

Model No.

③ A set product consisting of an LG shaft and an LG nut


2 LG4S +100L

Model No.

Overall LG shaft length

Number of LG nuts on one shaft
(no symbol for one nut)


Note) Model LG guide ball bushing available as LG shaft ①, or the LG nut ② separate.
A set consisting of an ③ LG shaft + an LG nut is also available if so desired.
A special radial clearance, designated grease application (standard type is applied only with antirust oil) and surface treatment (THK AP-C treatment, THK AP-CF treatment, THK AP-HC treatment) are also available.
Contact THK for details.



Unit: mm

	Basic load rating (radial)		Permissible torque	Permissible moment	Mass
	C N	C ₀ N	C _{0T} N·m	M _A N·m	g
	335	473	0.066	0.33	2.5
	466	757	0.105	0.71	4.0
	494	681	0.241	0.74	10.5
	860	1499	0.530	1.71	14.0
	796	1065	0.838	1.46	16.5
	1203	1916	1.509	2.66	22.0

Radial Clearance



Radial Clearance

Measurement of a radial clearance

Radial Clearance

Unit: μm

Normal clearance
0 to +10

LG Shaft

Material: SUJ2

Hardness: 56 to 64 HRC



LG shaft dimensions

Unit: mm

Model No.	Shaft diameter D ₀ h7	Standard length L					Maximum manufacturing length	Mass (g/m)
		100	150	200	250	300	200	220
LG4	4	100	150	—	—	—	150	95
LG6	6	100	150	200	—	—	200	220
LG8	8	100	150	200	250	—	250	390

Assembling the Guide Ball Bushing

Inner Diameter of the Housing

Table1 shows recommended housing inner-diameter tolerance for the Guide Ball Bushing. When fitting the Guide Ball Bushing with the housing, loose fit is normally recommended. If the clearance needs to be smaller, provide transition fit.


Table1 Housing Inner-diameter Tolerance

General conditions	H6
If the accuracy does not need to be very high	H7


Mounting the Nut

Although the Guide Ball Bushing does not require a large amount of strength for securing it in the LG shaft direction, do not support the nut only with driving fitting. For the housing inner-diameter tolerance, see Table1.


- Mounting model LG using a pin



- Mounting model LG as with the conventional Linear Bushing



Snap Ring



Stopper Plate

■ Snap Ring for Installation

To secure the Guide Ball Bushing model LG, snap rings indicated in Table2 are available.

Table2 Types of Snap Rings

Model No.	Snap ring	
	For inner surface	
	Needle snap ring	C-shape snap ring
LG 4	8	—
LG 6	12	12
LG 8	15	15

■ Set Screws Not Allowed

Securing the nut by pressing the outer surface with one set screw as shown in Fig.1 will cause the nut to be deformed.




Fig.1

[Incorporating the Nut]

When incorporating the Guide Ball Bushing into a housing, use a jig and drive in the nut, or use a flatter plate and gently hit the nut, instead of directly hitting the side plate or the seal. (see Fig.2).




Fig.2

Unit: mm

Model No.	dr	Tolerance
LG 4S/LG 4L	3.6	-0.1 -0.3
LG 6S/LG 6L	5.6	
LG 8S/LG 8L	7.5	

[Inserting the LG Shaft]

When inserting the LG shaft into the Guide Ball Bushing, align the center of the shaft with that of the nut and gently insert the shaft straightforward into the nut. If the shaft is slanted while it is inserted, balls may fall off or the retainer may be deformed (see Fig.3).




Fig.3

[When Under a Moment Load]

When using the Guide Ball Bushing, make sure that the load is evenly distributed on the whole ball raceway. In particular, if a moment load is applied, use two or more Guide Ball Bushing units on the same LG shaft and secure an adequately large distance between the units.

If using the Guide Ball Bushing under a moment load, also calculate the equivalent radial load and identify the correct model number. (See **A4-11**.)

Lubrication

The Guide Ball Bushing requires grease or oil as a lubricant for its operation.

[Grease Lubrication]

Before mounting the product onto the LG shaft, apply grease to each row of balls inside the Guide Ball Bushing.

Thereafter apply grease as necessary, in accordance with usage and other conditions noted above, or attach housing as shown in Fig.1, or apply grease directly to the LG shaft.


We recommend using lithium soap-based grease No. 2.

[Oil Lubrication]

To lubricate, apply lubricant to the LG shaft one drop at a time, as needed, or attach housing as shown in Fig.1, in the same manner as when lubricating with grease.

Commonly used lubricants include turbine oil, machine oil, and spindle oil.

In addition to the procedures described the above, an oil hole or grease nipple can also be used for lubrication. For further information, contact THK.



Dust prevention

Entrance of dust or other foreign material into the Guide Ball Bushing will cause abnormal wear or shorten the service life. When entrance of dust or other foreign material is a possibility, it is important to select effective seals and/or dust-control device that meets the service environment conditions.

In addition, THK produces round bellows. Contact us for details.

Model Number Coding

Model number configurations differ depending on the model features. Refer to the corresponding sample model number configuration.

Guide Ball Bushing

Estimates and orders should be made for LG shafts alone or LG nuts alone in principle. A set consisting of an LG shaft and an LH nut is also available if desired by the customer. Contact THK for details.

Models LG-S and LG-L

- LG shaft only

LG4 -100L

Model No.
of LG shaft

Overall LG shaft length (in mm)

- LG nut only

LG4S

Model No. of LG nut

- Combination of
LG shaft and LG nut

2 LG4S +100L

Model No.
of LG nut

Overall LG shaft length (in mm)

Number of LG nuts on one shaft
(no symbol for one nut)

A special radial clearance, designated grease application (standard product is applied with antirust oil only), and surface treatment (THK AP-C treatment, THK AP-CF treatment, THK AP-HC treatment) are also available. Contact THK for details.

[Handling]

- (1) Disassembling each part may cause dust to enter the system or degrade mounting accuracy of parts. Do not disassemble the product.
- (2) Take care not to drop or strike the Guide Ball Bushing. Doing so may cause injury or damage. Giving an impact to it could also cause damage to its function even if the product looks intact.
- (3) When handling the product, wear protective gloves, safety shoes, etc., as necessary to ensure safety.

[Precautions on Use]

- (1) Prevent foreign material, such as cutting chips or coolant, from entering the product. Failure to do so may cause damage.
- (2) If the product is used in an environment where cutting chips, coolant, corrosive solvents, water, etc., may enter the product, use bellows, covers, etc., to prevent them from entering the product.
- (3) Do not use the product at temperature of 80°C or higher. Exposure to higher temperatures may cause the resin/rubber parts to deform/be damaged.
- (4) If foreign material such as cutting chips adheres to the product, replenish the lubricant after cleaning the product.
- (5) Micro-strokes tend to obstruct oil film to form on the raceway in contact with the rolling element, and may lead to fretting corrosion. Take consideration using grease offering excellent fretting prevention. It is also recommended that a stroke movement corresponding to the length of the outer cylinder be made on a regular basis to make sure oil film is formed between the raceway and rolling element.
- (6) Do not use undue force when fitting parts (pin, key, etc.) to the product. This may generate permanent deformation on the raceway, leading to loss of functionality.
- (7) Insert the shaft straight through the opening. Inserting the shaft at an angle can introduce foreign matter, damage internal components, or cause balls to fall out.
- (8) Using this product with any balls removed may result in premature damage.
- (9) Please contact THK if any balls fall out; do not use the product if any balls are missing.
- (10) If an attached component is insufficiently rigid or mounted incorrectly, the bearing load will be concentrated at one location and performance will decline significantly. Make sure the housing and base are sufficiently rigid, the anchoring bolts are strong enough, and the component is mounted correctly.

[Lubrication]

- (1) Thoroughly wipe off anti-rust oil and feed lubricant before using the product.
- (2) Do not mix different lubricants. Mixing greases using the same type of thickening agent may still cause adverse interaction between the two greases if they use different additives, etc.
- (3) When using the product in locations exposed to constant vibrations or in special environments such as clean rooms, vacuum and low/high temperature, use the grease appropriate for the specification/environment.
- (4) To lubricate the product, apply lubricant directly to the raceway surface and execute a few preliminary strokes to ensure that the interior is fully lubricated.
- (5) The consistency of grease changes according to the temperature. Take note that the slide resistance of the Guide Ball Bushing also changes as the consistency of grease changes.

- (6) After lubrication, the slide resistance of the Guide Ball Bushing may increase due to the agitation resistance of grease. Be sure to perform a break-in to let the grease spread fully, before operating the machine.
- (7) Excess grease may scatter immediately after lubrication, so wipe off scattered grease as necessary.
- (8) The properties of grease deteriorate and its lubrication performance drops over time, so grease must be checked and added properly according to the use frequency of the machine.
- (9) The greasing interval varies depending on the use condition and service environment. Set the final lubrication interval/amount based on the actual machine.

[Assembling the LG Nut with the LG Shaft of the Guide Ball Bushing]

- (1) When assembling the LG nut with the LG shaft, align the position of the balls inside the LG nut with the position of the groove of the LG shaft, then insert the LG shaft into the LG nut straightforward and gradually. If the LG shaft is tilted when it is inserted, balls may bounce out or damage the circulating part.
- (2) If the LG shaft is stuck in the middle of insertion, do not force it into the nut. Instead, but pull it out first, re-check the ball position and the LG shaft groove position, and then insert it straightforward and gradually.
- (3) After assembling the LG nut with the LG shaft, check that the LG nut or the LG shaft smoothly moves. If the shaft was forced into the nut, function could be lost even if the product looks intact.

[Storage]

When storing the Guide Ball Bushing, enclose it in a package designated by THK and store it in a room while avoiding high temperature, low temperature and high humidity.

[Disposal]

Dispose of the product properly as industrial waste.

Features of the Linear Bushing




Fig.1 Structure of Linear Bushing Model LM-...UU

Structure and Features

The linear bushing is a linear motion product that is used in combination with a cylindrical LM shaft. The ball bearings in the load area offer point contact with the LM shaft. This allows straight motion with minimal friction resistance and therefore smooth motion.

High-carbon chromium bearing steel is used for the nut, and the outer and inner surfaces are ground and heat-treated.

Linear bushings are used for medical equipment, packing equipment, and lightweight OA equipment that is not subject to vibration, shock, etc.

However, they cannot be used for applications in which loads are applied in a rotational direction.

[Interchangeability]

The linear bushing and LM shaft are interchangeable, allowing for use in any combination.

[Low Noise]

A molded resin retainer is incorporated into the standard type in order to prevent the balls from falling out. This also provides silent and smooth operation.

[Wide Array of Types]

A wide array of types are available, such as the Standard Type, Clearance-adjustable Type, Open Type, Long Type, Fitted Flange Type, and Flanged Linear Bushing, allowing the user to select a type that suits the intended application.

Types of the Linear Ball Bushing


Types and Features

Standard Type

Specification Table⇒ [A4-42/A4-44/A4-46/A4-48](#)

The most standard type with a wide range of applications.

- Model LM SUJ2 Type
This product series has commonly used dimensions
- Model LM-GA SUJ2 Type
Features the Model LM-GA metal retainer
- Model LM-MG SUS Type
- Model LME SUJ2 Type
This product series has dimensions commonly used in Europe



Standard Type


Clearance-adjustable Type

Specification Table⇒ [A4-42/A4-44/A4-46/A4-48](#)

A standard nut with a slit in the direction of the LM shaft.

The clearance between the LM shaft and housing can be adjusted by installing the shaft to a housing with an adjustable inner diameter.

- Models LM-AJ/LM-GA-AJ/LME-AJ... Made of SUJ2
- Model LM-MG-AJ SUS Type



Clearance-adjustable Type


Open Type

Specification Table⇒ [A4-42/A4-44/A4-46/A4-48](#)

The nut features a cut equal to the width of one row of ball bearings (50° to 80°).

This enables it to be used even in locations where the LM shaft is supported by a column or fulcrum. In addition, the clearance can be adjusted.

- Models LM-OP/LM-GA-OP/LME-OP... Made of SUJ2
- Model LM-MGA-OP SUS Type




Open Type

Long Type

Incorporates two standard type retainers, giving it a large net rated load.

Model LM-L SUJ2 Type

Specification Table⇒ **A4-50**



Long Type


Flanged Type (Round)

Easy to mount because the spline nut can be directly attached to the housing.

Model LMF SUJ2 Type

Model LMF-M SUS Type

Specification Table⇒ **A4-52/A4-54**



Flanged Type (Round)


Flanged Type (Round) - Long

Incorporates two standard type retainers, giving it a large net rated load.

Model LMF-L SUJ2 Type

Model LMF-ML SUS Type

Specification Table⇒ **A4-56/A4-58**



Flanged Type (Round) - Long

Flanged Type (Square)


Features a Model LMF flange that has been flattened on four sides.

The lower core height compared to circular flanges allows for more compact designs.

Model LMK SUJ2 Type

Model LMK-M SUS Type

Specification Table⇒ [A4-60/A4-62](#)



Flanged Type (Square)


Flanged Type (Square) - Long

Incorporates two standard type retainers, giving it a large net rated load.

Model LMK-L SUJ2 Type

Model LMK-ML SUS Type

Specification Table⇒ [A4-64/A4-66](#)



Flanged Type (Square) - Long

Lightweight Flanged Type (Square)

NEW


Specification Table⇒ [A4-68](#)

Features a flange made using high strength plastic.

Weighs less than metal flanges.

Mounting this type to moving parts reduces the overall weight.

Model LMJK SUJ2 Type



Lightweight Flanged Type (Square)


Lightweight Flanged Type (Square) - Long

NEW

Specification Table⇒ [A4-70](#)

Incorporates two standard type retainers, giving it a large net rated load.

Model LMJK-L SUJ2 Type



Lightweight Flanged Type (Square) - Long

Flanged Type (Cut Flange)

Features a Model LMF flange that has been flattened on two sides.


The lower core height compared to square flanges allows for more compact designs.

The rows of bearings are aligned so that a load from one of the flattened sides will be supported by two rows of bearings.

Model LMH SUJ2 Type

Model LMH-M SUS Type

Specification Table⇒ **A4-72/A4-74**



Flanged Type (Cut Flange)


Flanged Type (Cut Flange) - Long

Incorporates two standard type retainers, giving it a large net rated load.

Model LMH-L SUJ2 Type

Model LMH-ML SUS Type

Specification Table⇒ **A4-76/A4-78**




Flanged Type (Cut Flange) - Long

Fitted Flanged Type (Round)

Specification Table⇒ **A4-80**

Since the fitted part is short, the linear bushing tends not to protrude into the other side, so space is saved on the side opposite the mounting.

Model LMIF SUJ2 Type



Fitted Flanged Type (Round)


Fitted Flanged Type (Round) - Long

Specification Table⇒ **A4-82**

Model LMIF - Long.

Incorporates two standard type retainers, giving it a large net rated load.

Model LMIF-L SUJ2 Type




Fitted Flanged Type (Round) - Long

Center Flanged Type (Round) - Long

Specification Table⇒ **A4-84**

As work pieces can be mounted around the center of the nut, the load can be distributed and spaced evenly on either side of the flange. Ideal for making the stroke even in both directions.

Model LCMF-L SUJ2 Type



Center Flanged Type (Round) - Long


Fitted Flanged Type (Square)

Specification Table⇒ **A-4-86**

The flange is similar to the Model LMIF, but flattened in four places.

The lower core height compared to circular flanges allows for more compact designs.

Model LMIK SUJ2 Type




Fitted Flanged Type (Square)

Fitted Flanged Type (Square) - Long

Specification Table⇒ **A-4-88**

Incorporates two standard type retainers, giving it a large net rated load.

Model LMIK-L SUJ2 Type




Fitted Flanged Type (Square) - Long

Center Flanged Type (Square) - Long

Specification Table⇒ **A-4-90**

As work pieces can be mounted around the center of the nut, the load can be distributed and spaced evenly on either side of the flange. Ideal for making the stroke even in both directions.

Model LMCK-L SUJ2 Type



Center Flanged Type (Square) - Long

Fitted Flanged Type (Ovular)


Features a Model LMIF flange that has been flattened on two sides.

The lower core height compared to square flanges allows for more compact designs.

The rows of bearings are aligned so that a load from one of the flattened sides will be supported by two rows of bearings.

Model LMIH SUJ2 Type

Specification Table⇒ **A4-92**




Fitted Flanged Type (Ovular)

Fitted Flanged Type (Ovular) - Long

Incorporates two standard type retainers, giving it a large net rated load.

Model LMIH-L SUJ2 Type

Specification Table⇒ **A4-94**




Fitted Flanged Type (Ovular) - Long

Center Flanged Type (Ovular) - Long

As work pieces can be mounted around the center of the nut, the load can be distributed and spaced evenly on either side of the flange. Ideal for making the stroke even in both directions.

Model LMCH-L SUJ2 Type

Specification Table⇒ **A4-96**




Center Flanged Type (Ovular) - Long

Linear Bushing Model SC

It is a case unit where the standard type of Linear Bushing is incorporated into a small, light-weight aluminum casing. This model can easily be mounted simply by securing it to the table with bolts.

Specification Table⇒ **A4-98**




Linear Bushing Model SC

Linear Bushing (Long) Model SL

A case unit that features two standard linear bushings embedded within an aluminum casing.

Specification Table⇒ **A4-102**




Linear Bushing (Long) Model SL

Linear Bushing Model SH

Specification Table⇒ **A4-104**

It is a case unit where the standard type of Linear Bushing is incorporated into a smaller and lighter aluminum casing than model SC. This model allows even more compact design than model SC. It also has flexibility in mounting orientation. Additionally, it is structured so that two rows of balls receive the load from the top of the casing, allowing a long service life to be achieved.




Linear Bushing Model SH

Linear Bushing (Long) Model SH-L

Specification Table⇒ **A4-106**

A long version of model SH, this model is a case unit that contains two units of the standard type Linear Bushing in an aluminum casing.



Linear Bushing (Long) Model SH-L

Standard LM Shafts

LM shafts for use with the high quality linear bushing model LM series.

Specification Table⇒A4-109



Standard LM Shafts

Build-to-order LM Shafts

Machined shaft ends available upon request.

Specification Table⇒A4-111




Build-to-order LM Shafts

LM Shaft End Support Model SK

A lightweight aluminum fulcrum for securing an LM shaft.


Allows the LM shaft to be secured without having to machine the LM shaft ends.


Specification Table⇒A4-108



LM Shaft End Support Model SK

Classification Table






Flowchart for Selecting a Linear Bushing

Steps for Selecting a Linear Bushing

The following flowchart should be used as a guide for selecting a Linear Bushing.








Rated Load and Nominal Life

Load Rating

The rated load of the Linear Bushing varies according to the position of balls in relation to the load direction. The basic load ratings indicated in the specification tables each indicate the value when one row of balls receiving a load are directly under the load.

If the Linear Bushing is mounted so that two rows of balls evenly receive the load in the load direction, the rated load changes as shown in Table1.

Table1 Rated load of the Linear Bushing

Rows of balls	Ball position	Load Rating
3 rows		$1 \times C$
4 rows		$1.41 \times C$
5 rows		$1.46 \times C$
6 rows		$1.28 \times C$
8 rows		$1.25 \times C$

For specific values for "C" above, see the respective specification table.

[Calculating the Nominal Life]

The nominal life of the THK linear bushing is defined as 50 km. The nominal life (L₁₀) is calculated from the basic dynamic load rating (C) and the load acting on the linear bushing (P_c) using the following formula.

$$L_{10} = \left(\frac{C}{P_c}\right)^3 \times 50 \dots\dots\dots(1)$$

L₁₀ : Nominal life

(km)

C : Basic dynamic load rating

(N)

P_c : Calculated load

(N)

*This nominal life formula may not apply if the length of the stroke is less than or equal to twice the length of the nut.

When comparing the nominal life (L₁₀), you must take into account whether the basic dynamic load rating was defined based on 50 km or 100 km. Convert the basic dynamic load rating based on ISO 14728-1 as necessary.

ISO-regulated basic dynamic load rating conversion formula:

$$C_{100} = \frac{C_{50}}{1.26}$$

C₅₀ : Basic dynamic load rating based on a nominal life of 50 km

C₁₀₀ : Basic dynamic load rating based on a nominal life of 100 km

[Calculating the Modified Nominal Life]

During use, a linear bushing may be subjected to vibrations and shocks as well as fluctuating loads, which are difficult to detect. In addition, the surface hardness of the raceways, the operating temperature, and having blocks arranged directly behind one another will have a decisive impact on the service life. Taking these factors into account, the modified nominal life (L_{10m}) can be calculated according to the following formula (2).

•Modified factor α

$$\alpha = \frac{f_H \cdot f_T \cdot f_c}{f_W}$$

α : Modified factor

f_H : Hardness factor

(see Fig.1 on A4-39)

f_T : Temperature factor

(see Fig.2 on A4-39)

f_c : Contact factor

(see Table2 on A4-40)

f_W : Load factor

(see Table 3 on A4-40)

•Modified nominal life L_{10m}

$$L_{10m} = \left(\alpha \times \frac{C}{P_c}\right)^3 \times 50 \dots\dots\dots(2)$$

L_{10m} : Modified nominal life

(km)

C : Basic dynamic load rating

(N)

P_c : Calculated load

(N)

● **When a Moment Load is Applied to a Single Nut or Two Nuts in Close Contact with Each Other**

When a moment load is applied to a single nut or two nuts in close contact with each other, calculate the equivalent radial load at the time the moment is applied.

$$P_u = K \cdot M$$

P_u : Equivalent radial load (N)
(with a moment applied)

K : Equivalent factors
(see Table4 to Table6 on **A4-41**)

M : Applied moment (N·mm)

However, " P_u " is assumed to be within the basic static load rating (C_0).

● **When a Moment Load and a Radial Load are Simultaneously Applied**

When a moment and a radial load are applied simultaneously, calculate the service life based on the sum of the radial load and the equivalent radial load.

■ **f_H : Hardness Factor**

To maximize the load capacity of the Linear Bushing, the hardness of the raceways needs to be between 58 to 64 HRC.

If the hardness is lower than this range, the basic dynamic load rating and the basic static load rating decrease. Therefore, it is necessary to multiply each rating by the respective hardness factor (f_H).

Normally, $f_H = 1.0$ since the Linear Bushing has sufficient hardness.




Fig.1 Hardness Factor (f_H)

■ **f_T : Temperature Factor**

If the temperature of the environment surrounding the operating Linear Bushing exceeds 100°C, take into account the adverse effect of the high temperature and multiply the basic load ratings by the temperature factor indicated in Fig.2.

Also note that the Linear Bushing itself must be of high temperature type.




Fig.2 Temperature Factor (f_T)

(Note) If the environment temperature exceeds 80°C, use a Linear Bushing type equipped with metal retainer plates.

■f_c: Contact Factor

When multiple nuts are used in close contact with each other, their linear motion is affected by moments and mounting accuracy, making it difficult to achieve uniform load distribution. In such applications, multiply the basic load rating (C) and (C₀) by the corresponding contact factor in Table2.

Note) If uneven load distribution is expected in a large machine, take into account the respective contact factor indicated in Table2.

Table2 Contact Factor (f_c)

Number of nuts in close contact with each other	Contact factor f _c
2	0.81
3	0.72
4	0.66
5	0.61
Normal use	1

■f_w: Load Factor

In general, reciprocating machines tend to experience vibrations or impacts during operation, and it is extremely difficult to accurately determine the vibrations generated during high-speed operation and impacts during frequent starts and stops. Therefore, when the actual load applied to a linear bushing cannot be obtained, or when speed and impacts have a significant influence, divide the basic dynamic load rating (C) by the corresponding load factor in Table 3, which has been empirically obtained.

Table 3 Load Factor (f_w)

Vibrations/ impact	Speed(V)	f _w
Faint	Very low V≤0.25m/s	1 to 1.2
Weak	Slow 0.25<V≤1m/s	1.2 to 1.5
Medium	Medium 1<V≤2m/s	1.5 to 2
Strong	High V>2m/s	2 to 3.5

[Calculating the Service Life Time]

When the nominal life (L₁₀) has been obtained, if the stroke length and the number of reciprocations per minute are constant, the service life time is obtained using the following equation.

$$L_h = \frac{L_{10} \times 10^3}{2 \times \ell_s \times n_1 \times 60}$$

- L_h

:

Service life time

(h)
- ℓ_s

:

Stroke length

(m)
- n₁

:

Number of reciprocations per minute

(min⁻¹)

Table of Equivalent Factors

Table4 Equivalent Factors of Model LM

Model No.	Equivalent factor: K	
	Single nut	Double blocks
LM 3	1.566	0.26
LM 4	1.566	0.21
LM 5	1.253	0.178
LM 6	0.553	0.162
LM 8S	0.708	0.166
LM 8	0.442	0.128
LM 10	0.389	0.101
LM 12	0.389	0.097
LM 13	0.343	0.093
LM 16	0.279	0.084
LM 20	0.257	0.071
LM 25	0.163	0.054
LM 30	0.153	0.049
LM 35	0.143	0.045
LM 38	0.127	0.042
LM 40	0.117	0.04
LM 50	0.096	0.032
LM 60	0.093	0.028
LM 80	0.077	0.022
LM 100	0.065	0.017
LM 120	0.051	0.015

Note) Equivalent factors for the following models are the same as for model LM: Models LMF, LMK, LMIF, LMIK, LMIH, LMH, and SC.

Table5 Equivalent Factors of Model LM-L

Model No.	Equivalent factor: K
	Single nut
LM 3L	0.654
LM 4L	0.578
LM 5L	0.446
LM 6L	0.402
LM 8L	0.302
LM 10L	0.236
LM 12L	0.226
LM 13L	0.214
LM 16L	0.192
LM 20L	0.164
LM 25L	0.12
LM 30L	0.106
LM 35L	0.1
LM 40L	0.086
LM 50L	0.068
LM 60L	0.062

Note) Equivalent factors for the following models are the same as for model LM-L: Models LMF-L, LMK-L, LMH-L, LMIF-L, LMIK-L, LMIH-L, LMCF-L, LMCK-L, and LMCH-L.

Table6 Equivalent Factors of Model LME

Model No.	Equivalent factor: K	
	Single nut	Double blocks
LME 5	0.669	0.123
LME 8	0.514	0.116
LME 12	0.389	0.09
LME 16	0.343	0.081
LME 20	0.291	0.063
LME 25	0.209	0.052
LME 30	0.167	0.045
LME 40	0.127	0.039
LME 50	0.105	0.031
LME 60	0.093	0.024
LME 80	0.077	0.018

Precautions To Be Taken if an Eccentric Load Is Applied

Since Linear Bushing is not suitable for application of an eccentric load, we recommend using Guide Ball Bushing or Ball Spline.


Accuracy Standards

[Linear Bushing]

The accuracy of the Linear Bushing in inscribed bore diameter, outer diameter, width and eccentricity is described in the corresponding specification table. The accuracy of mode LM in inscribed bore diameter and eccentricity is classified into high accuracy grade (no symbol) and precision grade (P). (Accuracy symbol is expressed at the end of the model number.)

For the clearance-adjustable type (-AJ) and open type (-OP), the inscribed bore diameter tolerance, the outer diameter tolerance, and the eccentricity indicate the values before the division of the nut.


Model LM




Model No.			Ball rows	Main						
Standard type	Clearance- adjustable type	Open type		Inscribed bore diameter			Outer diameter		Length	
				dr	Tolerance		D	Tolerance High/Precision	L	Tolerance
					High	Precision				
LM 3	—	—	4	3	0	0	7	0	10	0
LM 4	—	—	4	4			−0.008		−0.005	
LM 5	—	—	4	5	0	0	10	−0.011	15	0
LM 6	LM 6-AJ	—	4	6			12		19	
LM 8S	LM 8S-AJ	—	4	8			15		17	
LM 8	LM 8-AJ	—	4	8			15		24	
LM 10	LM 10-AJ	—	4	10			19	29		
LM 12	LM 12-AJ	—	4	12			21	30		
LM 13	LM 13-AJ	LM 13-OP	4	13			23	32		
LM 16	LM 16-AJ	LM 16-OP	5	16			28	37		
LM 20	LM 20-AJ	LM 20-OP	5	20	0	0	32	0	42	
LM 25	LM 25-AJ	LM 25-OP	6	25			40		59	
LM 30	LM 30-AJ	LM 30-OP	6	30			45		64	
LM 35	LM 35-AJ	LM 35-OP	6	35	0	0	52	0	70	0
LM 40	LM 40-AJ	LM 40-OP	6	40			60		80	
LM 50	LM 50-AJ	LM 50-OP	6	50			80		100	
LM 60	LM 60-AJ	LM 60-OP	6	60	0	0	90	0	110	−0.022
					−0.015	−0.009				

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If the ambient temperature exceeds 80°C, use the type equipped with a metal retainer (model LM-GA).
If requiring a type equipped with a seal, indicate it when placing an order.
(Example) LM13 UU


Seal attached on both ends of the nut
For the clearance-adjustable type (-AJ) and open type (-OP), the inscribed bore diameter tolerance, the outer diameter tolerance, and the eccentricity indicate the values before the division of the nut.



Model LM



Model LM-AJ




Model LM-OP

Unit: mm

dimensions								Eccentricity (max)		Radial clearance tolerance μm	Basic load rating		Mass g
	L ₁	Tolerance	L ₂	D ₀	h ₀	h ₁	θ°	μm					
								High	Precision				
	—	—	—	—	—	—	—	8	4	−2	88.2	108	1.6
	—	—	—	—	—	—	—	8	4	−3	88.2	127	2.2
	10.2	0 −0.2	1.1	9.6	—	—	—	8	4	−3	167	206	4
	13.5		1.1	11.5	1	—	—	12	8	−5	206	265	8
	11.5		1.1	14.3	1	—	—	12	8	−5	176	225	9.3
	17.5		1.1	14.3	1	—	—	12	8	−5	265	402	13.5
	22		1.3	18	1	—	—	12	8	−5	373	549	25
	23		1.3	20	1.5	—	—	12	8	−5	412	598	28
	23		1.3	22	1.5	9	80	12	8	−7	510	775	38
	26.5		1.6	27	1.5	11	60	12	8	−7	775	1180	78
	30.5		1.6	30.5	1.5	11	60	15	10	−9	863	1370	86
	41	0 −0.3	1.85	38	2	12	50	15	10	−9	980	1570	210
	44.5		1.85	43	2.5	15	50	15	10	−9	1570	2750	221
	49.5		2.1	49	2.5	17	50	20	12	−13	1670	3140	358
	60.5		2.1	57	3	20	50	20	12	−13	2160	4020	557
	74		2.6	76.5	3	25	50	20	12	−13	3820	7940	1418
	85		3.15	86.5	3	30	50	25	17	−16	4710	10000	1733

Note) When using the Linear Bushing on a single shaft, use two or more units (instead of one unit) on the same shaft to avoid a moment load, and secure a large distance between the units.
If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LM-GA (Metal Retainer Type)




Model No.			Ball rows	Main								
Standard type	Clearance- adjustable type	Open type		Inscribed bore diameter		Outer diameter		Length				
				dr	Tolerance		D	Tolerance High/Precision	L	Tolerance		
					High	Precision						
LM 6GA	—	—	3	6	0 -0.009	0 -0.006	12	0 -0.011	19	0 -0.2		
LM 8SGA	—	—	3	8			15		17			
LM 8GA	—	—	3	8			15		24			
LM 10GA	—	—	4	10			19	29				
LM 12GA	LM 12GA-AJ	LM 12GA-OP	4	12			21	0 -0.013	30			
LM 13GA	LM 13GA-AJ	LM 13GA-OP	4	13			23	32				
LM 16GA	LM 16GA-AJ	LM 16GA-OP	4	16	0 -0.010	0 -0.007	28	0 -0.016	37	0 -0.3		
LM 20GA	LM 20GA-AJ	LM 20GA-OP	5	20			32		42			
LM 25GA	LM 25GA-AJ	LM 25GA-OP	5	25			40		59			
LM 30GA	LM 30GA-AJ	LM 30GA-OP	6	30			45	64				
LM 35GA	LM 35GA-AJ	LM 35GA-OP	6	35			52	70				
LM 38GA	LM 38GA-AJ	LM 38GA-OP	6	38			57	0 -0.019	76			
LM 40GA	LM 40GA-AJ	LM 40GA-OP	6	40	0 -0.012	0 -0.008	60	0 -0.022	80	0 -0.4		
LM 50GA	LM 50GA-AJ	LM 50GA-OP	6	50			80		100			
LM 60GA	LM 60GA-AJ	LM 60GA-OP	6	60			90		110			
LM 80GA	LM 80GA-AJ	LM 80GA-OP	6	80			0 -0.015	0 -0.009	120		140	
LM 100GA	LM 100GA-AJ	LM 100GA-OP	6	100			0 -0.020	0 -0.010	150		0 -0.025	175
LM 120A	LM 120A-AJ	LM 120A-OP	8	120					180			200

Note) If requiring a type equipped with a seal, indicate it when placing an order. (seal heat resistance: 80℃.)


(Example) LM50GA UU

Seal attached on both ends of the nut


For the clearance-adjustable type (-AJ) and open type (-OP), the inscribed bore diameter tolerance, the outer diameter tolerance, and the eccentricity indicate the values before the division of the nut.



Model LM-GA



Model LM-GA-AJ



Model LM-GA-OP

Unit: mm

dimensions								Greasing hole	Eccentricity (max) μm		Radial clearance tolerance	Basic load rating		Mass
	L ₁	Tolerance	L ₂	D ₀	h ₀	h ₁	θ°	d ₀	High	Precision	μm	C N	C ₀ N	g
	13.5	0 -0.2	1.1	11.5	—	—	—	—	12	8	-5	206	265	7
	11.5		1.1	14.3	—	—	—	—	12	8	-5	176	225	10
	17.5		1.1	14.3	—	—	—	—	12	8	-5	265	402	14
	22		1.3	18	—	—	—	2	12	8	-5	373	549	27
	23		1.3	20	1.5	7.5	80	2	12	8	-5	412	598	31
	23		1.3	22	1.5	9	80	2	12	8	-7	510	775	41
	26.5		1.6	27	1.5	11	60	2.3	12	8	-7	775	1180	69
	30.5	0 -0.3	1.6	30.5	2	11	60	2.3	15	10	-9	863	1370	92
	41		1.85	38	2	13	60	3	15	10	-9	980	1570	200
	44.5		1.85	43	2.5	15	50	3	15	10	-9	1570	2750	250
	49.5		2.1	49	2.5	17	50	3	20	12	-13	1670	3140	370
	58.5		2.1	54.5	3	18	50	3	20	12	-13	2160	4020	490
	60.5		2.1	57	3	20	50	3	20	12	-13	2160	4020	590
	74		2.6	76.5	3	25	50	4	20	12	-13	3820	7940	1500
	85	0 -0.4	3.15	86.5	3	30	50	4	25	17	-16	4710	10000	1850
	105.5		4.15	116	3	40	50	4	25	17	-16	7350	16000	4200
	125.5		4.15	145	3	50	50	4	30	20	-20	14100	34800	8200
	158.6		4.15	175	4	85	80	5	30	20	-25	16400	40000	15500


Note) When using the Linear Bushing on a single shaft, use two or more bushings on the same shaft to minimize a moment load, and secure a large distance between the units.

Model LM-GA has oil holes as a standard feature.

If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.

For further information, contact THK.

Model LM-MG (Stainless Steel Type)



Model No.			Ball rows	Main						
Standard type	Clearance- adjustable type	Open type		Inscribed bore diameter		Outer diameter		Length		
				dr	Tolerance		D	Tolerance High/Precision	L	Tolerance
					High	Precision				
LM 3M	—	—	4	3	0 -0.008	0 -0.005	7	0 -0.009	10	0 -0.12
LM 4M	—	—	4	4			8		12	
LM 5M	—	—	4	5			10		15	
* LM 6MG	LM 6MG-AJ	—	4	6	0 -0.009	0 -0.006	12	0 -0.011	19	0 -0.2
* LM 8SMG	LM 8SMG-AJ	—	4	8			15		17	
* LM 8MG	* LM 8MG-AJ	—	4	8			15		24	
* LM 10MG	* LM 10MG-AJ	—	4	10			19	29		
* LM 12MG	* LM 12MG-AJ	—	4	12			21	30		
* LM 13MG	* LM 13MG-AJ	* LM13MGA-OP	4	13			23	32		
* LM 16MG	* LM 16MG-AJ	* LM16MGA-OP	4	16	0 -0.010	0 -0.007	28	0 -0.013	37	0 -0.3
* LM 20MG	* LM 20MG-AJ	* LM20MGA-OP	5	20			32		42	
* LM 25MG	* LM 25MG-AJ	* LM25MGA-OP	5	25			40		59	
* LM 30MG	* LM 30MG-AJ	* LM30MGA-OP	6	30			45	64		
* LM 35MG	* LM 35MG-AJ	* LM35MGA-OP	6	35			52	70		
* LM 40MG	* LM 40MG-AJ	* LM40MGA-OP	6	40			-0.012	-0.008	60	


Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
 If the ambient temperature exceeds 80°C, use the type equipped with a metal retainer and indicate 'A' at the end of the model number.
 (For those marked with * in the table, metal retainers are available. Only metal retainer is available for open type.)
 (Metal retainer types of models LM6MG, 8SMG and 8MG each have 3 rows of balls.)

(Example) LM30MG A
 ————— High temperature symbol


If requiring a type equipped with a seal, indicate it when placing an order. (seal heat resistance: 80°C.)

(Example) LM30MG UU
 ————— Seal attached on both ends of the nut


For the clearance-adjustable type (-AJ) and open type (-OP), the inscribed bore diameter tolerance, the outer diameter tolerance, and the eccentricity indicate the values before the division of the nut.



Model LM-MG



Model LM-MG-AJ



Model LM-MG-OP

Unit: mm

dimensions								Eccentricity (max)		Radial clearance tolerance μm	Basic load rating		
	L ₁	Tolerance	L ₂	D ₀	h ₀	h ₁	θ°	High	Precision		C N	C ₀ N	Mass g
	—	—	—	—	—	—	—	8	4	-2	88.2	108	1.6
	—	—	—	—	—	—	—	8	4	-3	88.2	127	2.2
10.2			1.1	9.6	—	—	—	8	4	-3	167	206	4
13.5			1.1	11.5	1	—	—	12	8	-5	206	265	6
11.5			1.1	14.3	1	—	—	12	8	-5	176	225	9
17.5			1.1	14.3	1	—	—	12	8	-5	265	402	13
22			1.3	18	1	—	—	12	8	-5	373	549	23
23			1.3	20	1.5	—	—	12	8	-5	412	598	27
23			1.3	22	1.5	9	80	12	8	-7	510	775	35
26.5			1.6	27	1.5	11	80	12	8	-7	775	1180	59
30.5			1.6	30.5	1.5	11	60	15	10	-9	863	1370	79
41			1.85	38	2	12	50	15	10	-9	980	1570	170
44.5			1.85	43	2.5	15	50	15	10	-9	1570	2750	220
49.5			2.1	49	2.5	17	50	20	12	-13	1670	3140	330
60.5			2.1	57	3	20	50	20	12	-13	2160	4020	530


Note) Since the nut and the balls use stainless steel, these models are highly resistant to corrosion and environment.

If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.

For further information, contact THK.

When using the Linear Bushing on a single shaft, use two or more bushings on the same shaft to minimize a moment load, and secure a large distance between the units.

Model LME



Model No.			Ball rows	Main					
Standard type	Clearance- adjustable type	Open type		Inscribed bore diameter		Outer diameter		Length	
				dr	Tolerance	D	Tolerance	L	Tolerance
LME 5	LME 5-AJ	—	4	5	+0.008 0	12	0	22	0 -0.2
LME 8	LME 8-AJ	—	4	8		16	-0.008	25	
LME 12	LME 12-AJ	—	4	12		22	0	32	
LME 16	LME 16-AJ	LME 16-OP	5	16	+0.009	26	-0.009	36	0 -0.3
LME 20	LME 20-AJ	LME 20-OP	5	20	-0.001	32	0 -0.011	45	
LME 25	LME 25-AJ	LME 25-OP	6	25	+0.011	40		58	
LME 30	LME 30-AJ	LME 30-OP	6	30	-0.001	47	0	68	0 -0.3
LME 40	LME 40-AJ	LME 40-OP	6	40	+0.013 -0.002	62	0	80	
LME 50	LME 50-AJ	LME 50-OP	6	50		75	-0.013	100	
LME 60	LME 60-AJ	LME 60-OP	6	60		90	0 -0.015	125	0 -0.4
LME 80GA	LME 80GA-AJ	LME 80GA-OP	6	80	+0.016 -0.004	120		165	

Note) Since Linear Bushing models LME60 or smaller models are incorporated with a synthetic resin retainer, do not use them at temperature exceeding 80°C.

If the ambient temperature exceeds 80°C, use the type equipped with a metal retainer and indicate "A" at the end of the model number.

(Example) LME20G A


High temperature symbol

If requiring a type equipped with a seal, indicate it when placing an order. (seal heat resistance: 80°C.)


(Example) LME16 UU

Seal attached on both ends of the nut


For the clearance-adjustable type (-AJ) and open type (-OP), the inscribed bore diameter tolerance, the outer diameter tolerance, and the eccentricity indicate the values before the division of the nut.



Model LME



Model LME-AJ



Model LME-OP

Unit: mm

dimensions								Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass g
L ₁	Tolerance	L ₂	D ₀	h ₀	h ₁	θ°	μm			C N	C ₀ N	
14.5	0 -0.2	1.1	11.5	1	—	—	12	-5	-5	206	265	11.4
16.5		1.1	15.2	1	—	—	12	-5	-5	265	402	18.5
22.9		1.3	21	1.5	7.5	78	12	-7	-7	510	775	37
24.9		1.3	24.9	1.5	10	78	12	-7	-7	775	1180	52
31.5		1.6	30.3	2	10	60	15	-9	-9	863	1370	89
44.1	0 -0.3	1.85	37.5	2	12.5	60	15	-9	-9	980	1570	203
52.1		1.85	44.5	2	12.5	50	15	-9	-9	1570	2750	306
60.6		2.15	59	3	16.8	50	17	-13	-13	2160	4020	673
77.6		2.65	72	3	21	50	17	-13	-13	3820	7940	1025
101.7	0 -0.4	3.15	86.5	3	27.2	54	20	-16	-16	4710	10000	1914
133.7		4.15	116	3	36.3	54	20	-16	-16	7350	16000	4800

Note) If a metal retainer is used, the Linear Bushing has the shape as shown below.

When using the Linear Bushing on a single shaft, use two or more units (instead of one unit) on the same shaft to avoid a moment load, and secure a large distance between the units.


If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.

For further information, contact THK.



Model LME-GA

Model LM-L




Model LM-L

Model No.	Ball rows	Main					
		Inscribed bore diameter		Outer diameter		Length	
		dr	Tolerance	D	Tolerance	L	Tolerance
LM 3L	4	3	0 -0.010	7	0 -0.013	19	0 -0.3
LM 4L	4	4		8		23	
LM 5L	4	5		10		29	
LM 6L	4	6		12		35	
LM 8L	4	8		15	0 -0.016	45	
LM 10L	4	10		19		55	
LM 12L	4	12		21		57	
LM 13L	4	13		23		61	
LM 16L	5	16	0 -0.012	28	0 -0.019	70	0 -0.4
LM 20L	5	20		32		80	
LM 25L	6	25		40		112	
LM 30L	6	30		45	0 -0.022	123	
LM 35L	6	35	0 -0.015	52		135	
LM 40L	6	40		60		154	
LM 50L	6	50		80		192	
LM 60L	6	60	0 -0.020	90	0 -0.025	211	

(Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LM13L UU
└─── Seal attached on both ends of the nut




Unit: mm

dimensions					Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass
	L ₁	Tolerance	L ₂	D ₀	μm	μm	C N	C ₀ N	
	—	—	—	—	10	−2	139	216	3
	—	—	—	—	10	−3	139	254	4
	20	0 −0.3	1.1	9.6	10	−3	263	412	10
	27		1.1	11.5	15	−5	324	529	15
	35		1.1	14.3	15	−5	431	784	26
	44		1.3	18	15	−5	588	1100	48
	46		1.3	20	15	−5	657	1200	56
	46		1.3	22	15	−7	814	1570	75
	53		1.6	27	15	−7	1230	2350	147
	61		1.6	30.5	20	−9	1400	2750	163
	82		1.85	38	20	−9	1560	3140	397
	89	0 −0.4	1.85	43	20	−9	2490	5490	434
	99		2.1	49	25	−13	2650	6270	696
	121		2.1	57	25	−13	3430	8040	1087
	148		2.6	76.5	25	−13	6080	15900	2770
	170		3.15	86.5	25	−16	7650	20000	3340

Note) A stainless steel type (LM3ML to 30ML) is also available. Contact THK for details.
If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMF




Model LMF

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D _f	Tolerance
LMF 6	4	6	0 -0.009	12	0 -0.011	19	0 -0.2	28	0 -0.2
LMF 8S	4	8		15		17		32	
LMF 8	4	8		15		24		32	
LMF 10	4	10		19	0 -0.013	29		39	
LMF 12	4	12		21		30		42	
LMF 13	4	13		23		32		43	
LMF 16	5	16	0 -0.010	28	0 -0.016	37	0 -0.3	48	0 -0.3
LMF 20	5	20		32		42		54	
LMF 25	6	25		40		59		62	
LMF 30	6	30	0 -0.012	45	0 -0.019	64		74	
LMF 35	6	35		52		70		82	
LMF 40	6	40		60		80		96	
LMF 50	6	50	0 -0.015	80	0 -0.022	100		116	
LMF 60	6	60		90		110		134	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80℃.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMF25 UU
└─── Seal attached on both ends of the nut




Unit: mm

			Mounting hole $d_1 \times d_2 \times h$	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass g
				μm	μm	μm	C N	C ₀ N	
	H	PCD							
	5	20	3.4×6.5×3.3	12	12	-5	206	265	23
	5	24	3.4×6.5×3.3	12	12	-5	176	225	29
	5	24	3.4×6.5×3.3	12	12	-5	265	402	33
	6	29	4.5×8×4.4	12	12	-5	373	549	59
	6	32	4.5×8×4.4	12	12	-5	412	598	68
	6	33	4.5×8×4.4	12	12	-7	510	775	80
	6	38	4.5×8×4.4	12	12	-7	775	1180	126
	8	43	5.5×9.2×5.4	15	15	-9	863	1370	160
	8	51	5.5×9.2×5.4	15	15	-9	980	1570	305
	10	60	6.6×11×6.5	15	15	-9	1570	2750	422
	10	67	6.6×11×6.5	20	20	-13	1670	3140	583
	13	78	9×14×8.6	20	20	-13	2160	4020	960
	13	98	9×14×8.6	20	20	-13	3820	7940	1920
	18	112	11×17.5×10.8	25	25	-13	4710	10000	2720

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMF-M (Stainless Steel Type)




Model LMF-M

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D _i	Tolerance
LMF 6M	4	6	0 -0.009	12	0 -0.011	19	0 -0.2	28	0 -0.2
LMF 8SM	4	8		15		17		32	
LMF 8M	4	8		15		24		32	
LMF 10M	4	10		19	29	39			
LMF 12M	4	12		21	30	42			
LMF 13M	4	13	23	-0.013	32	43			
LMF 16M	5	16	28		37	48			
LMF 20M	5	20	32		42	54			
LMF 25M	6	25	0 -0.010	40	0 -0.016	59	0	62	
LMF 30M	6	30		45		64	-0.3	74	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMF20M UU

- Seal attached on both ends of the nut




Unit: mm

			Mounting hole $d_1 \times d_2 \times h$	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass g
				μm	μm	μm	C N	C ₀ N	
	H	PCD							
	5	20	3.4×6.5×3.3	12	12	-5	206	265	23
	5	24	3.4×6.5×3.3	12	12	-5	176	225	29
	5	24	3.4×6.5×3.3	12	12	-5	265	402	33
	6	29	4.5×8×4.4	12	12	-5	373	549	59
	6	32	4.5×8×4.4	12	12	-5	412	598	68
	6	33	4.5×8×4.4	12	12	-7	510	775	80
	6	38	4.5×8×4.4	12	12	-7	775	1180	126
	8	43	5.5×9.2×5.4	15	15	-9	863	1370	160
	8	51	5.5×9.2×5.4	15	15	-9	980	1570	305
	10	60	6.6×11×6.5	15	15	-9	1570	2750	422

Note) Since the nut and the balls use stainless steel, these models are highly resistant to corrosion and environment.
If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMF-L




Model LMF-L

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D1	Tolerance
LMF 6L	4	6	0 -0.010	12	0	35	0 -0.3	28	0 -0.2
LMF 8L	4	8		15	-0.013	45		32	
LMF 10L	4	10		19	0 -0.016	55		39	
LMF 12L	4	12		21		57		42	
LMF 13L	4	13		23		61		43	
LMF 16L	5	16	0 -0.012	28	0 -0.019	70	0 -0.4	48	0 -0.3
LMF 20L	5	20		32		80		54	
LMF 25L	6	25		40		112		62	
LMF 30L	6	30		45	0 -0.022	123		74	
LMF 35L	6	35		52		135		82	
LMF 40L	6	40	0 -0.015	60		154	0 -0.4	96	0 -0.3
LMF 50L	6	50		80		192		116	
LMF 60L	6	60	0 -0.020	90	0 -0.025	211		134	

(Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMF35L UU

└─── Seal attached on both ends of the nut




Unit: mm

	H	PCD	Mounting hole $d_1 \times d_2 \times h$	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass
				μm	μm	μm	C N	C ₀ N	g
	5	20	3.4×6.5×3.3	15	15	−5	324	529	29
	5	24	3.4×6.5×3.3	15	15	−5	431	784	45
	6	29	4.5×8×4.4	15	15	−5	588	1100	81
	6	32	4.5×8×4.4	15	15	−5	657	1200	93
	6	33	4.5×8×4.4	15	15	−7	814	1570	115
	6	38	4.5×8×4.4	15	15	−7	1230	2350	194
	8	43	5.5×9.2×5.4	20	20	−9	1400	2750	250
	8	51	5.5×9.2×5.4	20	20	−9	1560	3140	500
	10	60	6.6×11×6.5	20	20	−9	2490	5490	646
	10	67	6.6×11×6.5	25	25	−13	2650	6270	930
	13	78	9×14×8.6	25	25	−13	3430	8040	1488
	13	98	9×14×8.6	25	25	−13	6080	15900	3268
	18	112	11×17.5×10.8	25	25	−13	7650	20000	4342

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMF-ML (Stainless Steel Type)




Model LMF-ML

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMF 6ML	4	6	0 −0.010	12	0	35	0 −0.3	28	0 −0.2
LMF 8ML	4	8		15	−0.013	45		32	
LMF 10ML	4	10		19		55		39	
LMF 12ML	4	12		21	0	57		42	
LMF 13ML	4	13		23	−0.016	61		43	
LMF 16ML	5	16		28		70		48	
LMF 20ML	5	20	0 −0.012	32		80		54	
LMF 25ML	6	25		40	0	112	0	62	
LMF 30ML	6	30		45	−0.019	123	−0.4	74	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMF13ML UU

- Seal attached on both ends of the nut




Unit: mm

	H	PCD	Mounting hole $d_1 \times d_2 \times h$	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass
				μm	μm	μm	C N	C ₀ N	g
	5	20	3.4×6.5×3.3	15	15	-5	324	529	29
	5	24	3.4×6.5×3.3	15	15	-5	431	784	45
	6	29	4.5×8×4.4	15	15	-5	588	1100	81
	6	32	4.5×8×4.4	15	15	-5	657	1200	93
	6	33	4.5×8×4.4	15	15	-7	814	1570	115
	6	38	4.5×8×4.4	15	15	-7	1230	2350	194
	8	43	5.5×9.2×5.4	20	20	-9	1400	2750	250
	8	51	5.5×9.2×5.4	20	20	-9	1560	3140	500
	10	60	6.6×11×6.5	20	20	-9	2490	5490	646

Note) Since the nut and the balls use stainless steel, these models are highly resistant to corrosion and environment.
If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMK




Model LMK

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMK 6	4	6	0 -0.009	12	0 -0.011	19	0 -0.2	28	0 -0.2
LMK 8S	4	8		15		17		32	
LMK 8	4	8		15		24		32	
LMK 10	4	10		19	0 -0.013	29		39	
LMK 12	4	12		21		30		42	
LMK 13	4	13	0 -0.010	23		32		43	
LMK 16	5	16		28	0 -0.016	37		48	
LMK 20	5	20		32		42	0 -0.3	54	
LMK 25	6	25		40		59		62	
LMK 30	6	30		45	0 -0.019	64		74	
LMK 35	6	35	0 -0.012	52		70		82	0 -0.3
LMK 40	6	40		60		80		96	
LMK 50	6	50		80	0 -0.022	100		116	
LMK 60	6	60	0 -0.015	90		110		134	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMK13 UU

└── Seal attached on both ends of the nut




Unit: mm

				Mounting hole $d_1 \times d_2 \times h$	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass g
					μm	μm	μm	C N	C ₀ N	
	K	H	PCD	$d_1 \times d_2 \times h$	μm	μm	μm	C N	C ₀ N	Mass g
	22	5	20	$3.4 \times 6.5 \times 3.3$	12	12	-5	206	265	17
	25	5	24	$3.4 \times 6.5 \times 3.3$	12	12	-5	176	225	25
	25	5	24	$3.4 \times 6.5 \times 3.3$	12	12	-5	265	402	26
	30	6	29	$4.5 \times 8 \times 4.4$	12	12	-5	373	549	45
	32	6	32	$4.5 \times 8 \times 4.4$	12	12	-5	412	598	50
	34	6	33	$4.5 \times 8 \times 4.4$	12	12	-7	510	775	67
	37	6	38	$4.5 \times 8 \times 4.4$	12	12	-7	775	1180	105
	42	8	43	$5.5 \times 9.2 \times 5.4$	15	15	-9	863	1370	130
	50	8	51	$5.5 \times 9.2 \times 5.4$	15	15	-9	980	1570	270
	58	10	60	$6.6 \times 11 \times 6.5$	15	15	-9	1570	2750	344
	64	10	67	$6.6 \times 11 \times 6.5$	20	20	-13	1670	3140	487
	75	13	78	$9 \times 14 \times 8.6$	20	20	-13	2160	4020	790
	92	13	98	$9 \times 14 \times 8.6$	20	20	-13	3820	7940	1705
	106	18	112	$11 \times 17.5 \times 10.8$	25	25	-13	4710	10000	2278

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMK-M (Stainless Steel Type)




Model LMK-M

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D _f	Tolerance
Standard type									
LMK 6M	4	6	0 -0.009	12	0 -0.011	19	0 -0.2	28	0 -0.2
LMK 8SM	4	8		15		17		32	
LMK 8M	4	8		15		24		32	
LMK 10M	4	10		19	0 -0.013	29		39	
LMK 12M	4	12		21		30		42	
LMK 13M	4	13	0 -0.010	23		32		43	
LMK 16M	5	16		28	0 -0.016	37	0 -0.3	48	
LMK 20M	5	20		32		42		54	
LMK 25M	6	25		40		59		62	
LMK 30M	6	30		45		64		74	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMK25M UU

Seal attached on both ends of the nut




Unit: mm

					Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass
	K	H	PCD	Mounting hole $d_1 \times d_2 \times h$	μm	μm	μm	C N	C ₀ N	
	22	5	20	3.4×6.5×3.3	12	12	-5	206	265	17
	25	5	24	3.4×6.5×3.3	12	12	-5	176	225	25
	25	5	24	3.4×6.5×3.3	12	12	-5	265	402	26
	30	6	29	4.5×8×4.4	12	12	-5	373	549	45
	32	6	32	4.5×8×4.4	12	12	-5	412	598	50
	34	6	33	4.5×8×4.4	12	12	-7	510	775	67
	37	6	38	4.5×8×4.4	12	12	-7	775	1180	105
	42	8	43	5.5×9.2×5.4	15	15	-9	863	1370	130
	50	8	51	5.5×9.2×5.4	15	15	-9	980	1570	270
	58	10	60	6.6×11×6.5	15	15	-9	1570	2750	344

Note) Since the nut and the balls use stainless steel, these models are highly resistant to corrosion and environment.
 If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
 For further information, contact THK.

Model LMK-L




Model LMK-L

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMK 6L	4	6	0 -0.010	12	0	35	0 -0.3	28	0 -0.2
LMK 8L	4	8		15	-0.013	45		32	
LMK 10L	4	10		19	0 -0.016	55		39	
LMK 12L	4	12		21		57		42	
LMK 13L	4	13		23		61		43	
LMK 16L	5	16	0 -0.012	28	0 -0.019	70	0 -0.4	48	0 -0.3
LMK 20L	5	20		32		80		54	
LMK 25L	6	25		40		112		62	
LMK 30L	6	30		45	0 -0.022	123		74	
LMK 35L	6	35		52		135		82	
LMK 40L	6	40	0 -0.015	60		154	0 -0.4	96	0 -0.3
LMK 50L	6	50	0 -0.020	80	0 -0.025	192		116	
LMK 60L	6	60		90		211		134	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMK50L UU
└─── Seal attached on both ends of the nut




Unit: mm

					Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass g
	K	H	PCD	Mounting hole $d_1 \times d_2 \times h$	μm	μm	μm	C N	C ₀ N	
	22	5	20	3.4×6.5×3.3	15	15	-5	324	529	24
	25	5	24	3.4×6.5×3.3	15	15	-5	431	784	39
	30	6	29	4.5×8×4.4	15	15	-5	588	1100	68
	32	6	32	4.5×8×4.4	15	15	-5	657	1200	76
	34	6	33	4.5×8×4.4	15	15	-7	814	1570	100
	37	6	38	4.5×8×4.4	15	15	-7	1230	2350	176
	42	8	43	5.5×9.2×5.4	20	20	-9	1400	2750	210
	50	8	51	5.5×9.2×5.4	20	20	-9	1560	3140	466
	58	10	60	6.6×11×6.5	20	20	-9	2490	5490	569
	64	10	67	6.6×11×6.5	25	25	-13	2650	6270	825
	75	13	78	9×14×8.6	25	25	-13	3430	8040	1321
	92	13	98	9×14×8.6	25	25	-13	6080	15900	2952
	106	18	112	11×17.5×10.8	25	25	-13	7650	20000	3883

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMK-ML (Stainless Steel Type)




Model LMK-ML

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D1	Tolerance
LMK 6ML	4	6	0 -0.010	12	0	35	0 -0.3	28	0 -0.2
LMK 8ML	4	8		15	-0.013	45		32	
LMK 10ML	4	10		19	0 -0.016	55		39	
LMK 12ML	4	12		21		57		42	
LMK 13ML	4	13		23		61		43	
LMK 16ML	5	16	0 -0.012	28	0 -0.019	70	0 -0.4	48	
LMK 20ML	5	20		32		80		54	
LMK 25ML	6	25		40		112		62	
LMK 30ML	6	30		45		123		74	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMK8ML UU
└─── Seal attached on both ends of the nut




Unit: mm

	K	H	PCD	Mounting hole $d_1 \times d_2 \times h$	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass g
					μm	μm	μm	C N	C ₀ N	
	22	5	20	$3.4 \times 6.5 \times 3.3$	15	15	-5	324	529	24
	25	5	24	$3.4 \times 6.5 \times 3.3$	15	15	-5	431	784	39
	30	6	29	$4.5 \times 8 \times 4.4$	15	15	-5	588	1100	68
	32	6	32	$4.5 \times 8 \times 4.4$	15	15	-5	657	1200	76
	34	6	33	$4.5 \times 8 \times 4.4$	15	15	-7	814	1570	100
	37	6	38	$4.5 \times 8 \times 4.4$	15	15	-7	1230	2350	176
	42	8	43	$5.5 \times 9.2 \times 5.4$	20	20	-9	1400	2750	210
	50	8	51	$5.5 \times 9.2 \times 5.4$	20	20	-9	1560	3140	466
	58	10	60	$6.6 \times 11 \times 6.5$	20	20	-9	2490	5490	569

Note) Since the nut and the balls use stainless steel, these models are highly resistant to corrosion and environment.
If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMJK




Model LMJK

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMJK 8	4	8	0 -0.009	15	0 -0.011	24	0 -0.2	32	0 -0.2
LMJK 10	4	10		19	0 -0.013	29		39	
LMJK 12	4	12		21		30		42	
LMJK 16	5	16		28		37		48	
LMJK 20	5	20	0 -0.010	32	0 -0.016	42	0 -0.3	54	
LMJK 25	6	25		40		59		62	

Note) Includes synthetic resin; do not use in temperatures exceeding 80°C.
If seals must be attached, please specify when placing an order.


(Example) LMJK8 UU
└── Seal attached on both ends of the nut



Unit: mm

									Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass
	K	B	R	H	I	C	PCD	Mounting hole d ₁	μm	μm	μm	C	C ₀	
												N	N	
	25	10	R4	6	4	C3	24	3.4	12	12	-5	265	402	20
	30	12	R5	7	5		29	4.5				373	549	35
	32	13					32					412	598	38
	37	18					38				-7	775	1180	88
	42	21					43		863	1370		104		
	50	26	R6	10	6		51	5.5	15	15	-9	980	1570	234

Model LMJK-L




Model LMJK-L

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMJK 8L	4	8	0 -0.010	15	0 -0.013	45	0 -0.3	32	0 -0.2
LMJK 10L	4	10		19	0 -0.016	55		39	
LMJK 12L	4	12		21		57		42	
LMJK 16L	5	16		28		70		48	
LMJK 20L	5	20	0 -0.012	32	0 -0.019	80	0 -0.4	54	
LMJK 25L	6	25		40		112		62	

Note) Includes synthetic resin; do not use in temperatures exceeding 80°C.
If seals must be attached, please specify when placing an order.

(Example) LMJK8L UU


Seal attached on both ends of the nut




Unit: mm

									Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass
	K	B	R	H	I	C	PCD	Mounting hole d ₁	μm	μm	μm	C	C ₀	
												N	N	
	25	10	R4	6	4	C3	24	3.4	15	15	-5	431	784	32
	30	12	R5	7	5		29	4.5				588	1100	58
	32	13					32					657	1200	63
	37	18					38		20	20	-7	1230	2350	158
	42	21					43					1400	2750	182
	50	26	R6	10	6		51	5.5	20	20	-9	1560	3140	421

Model LMH



Models LMH6 to 13




Models LMH16 to 30

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMH 6	4	6	0 -0.009	12	0	19	-0.2	28	0 -0.2
LMH 8S	4	8		15	-0.011	17		32	
LMH 8	4	8		15	0 -0.013	24		32	
LMH 10	4	10		19		29		39	
LMH 12	4	12		21		30		42	
LMH 13	4	13		23		32		43	
LMH 16	5	16	0 -0.010	28	0 -0.016	37	-0.3	48	
LMH 20	5	20		32		42		54	
LMH 25	6	25		40		59	0	62	
LMH 30	6	30		45		64	-0.3	74	

(Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMH16 UU
_____ Seal attached on both ends of the nut




Unit: mm


	K	H	B	C	Mounting hole $d_1 \times d_2 \times h$	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass g
						μm	μm	μm	C N	C ₀ N	
	18	5	20	—	3.4×6.5×3.3	12	12	−5	206	265	20
	21	5	24	—	3.4×6.5×3.3	12	12	−5	176	225	24
	21	5	24	—	3.4×6.5×3.3	12	12	−5	265	402	28
	25	6	29	—	4.5×8×4.4	12	12	−5	373	549	50
	27	6	32	—	4.5×8×4.4	12	12	−5	412	598	56
	29	6	33	—	4.5×8×4.4	12	12	−7	510	775	69
	34	6	31	22	4.5×8×4.4	12	12	−7	775	1180	111
	38	8	36	24	5.5×9.2×5.4	15	15	−9	863	1370	140
	46	8	40	32	5.5×9.2×5.4	15	15	−9	980	1570	279
	51	10	49	35	6.6×11×6.5	15	15	−9	1570	2750	351

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMH-M (Stainless Steel Type)



Models LMH 6M to 13M




Models LMH 16M to 30M

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMH 6M	4	6	0 -0.009	12	0	19	0 -0.2	28	0 -0.2
LMH 8SM	4	8		15	-0.011	17		32	
LMH 8M	4	8		15	0 -0.013	24		32	
LMH 10M	4	10		19		29		39	
LMH 12M	4	12		21		30		42	
LMH 13M	4	13	0 -0.010	23	0 -0.016	32	0 -0.3	43	
LMH 16M	5	16		28		37		48	
LMH 20M	5	20		32		42		54	
LMH 25M	6	25		40		59		62	
LMH 30M	6	30		45		64		74	

Note) Since this model contains a synthetic resin retainer, do not use it in temperatures exceeding 80°C.
If an equipped seal is required, please specify when placing an order.

(Example) LMH16M UU

└── Seal attached on both ends of the nut




Unit: mm


	K	H	B	C	Mounting hole $d_1 \times d_2 \times h$	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass g
						μm	μm	μm	C N	C ₀ N	
	18	5	20	—	3.4×6.5×3.3	12	12	-5	206	265	20
	21	5	24	—	3.4×6.5×3.3	12	12	-5	176	225	24
	21	5	24	—	3.4×6.5×3.3	12	12	-5	265	402	28
	25	6	29	—	4.5×8×4.4	12	12	-5	373	549	50
	27	6	32	—	4.5×8×4.4	12	12	-5	412	598	56
	29	6	33	—	4.5×8×4.4	12	12	-7	510	775	69
	34	6	31	22	4.5×8×4.4	12	12	-7	775	1180	111
	38	8	36	24	5.5×9.2×5.4	15	15	-9	863	1370	140
	46	8	40	32	5.5×9.2×5.4	15	15	-9	980	1570	279
	51	10	49	35	6.6×11×6.5	15	15	-9	1570	2750	351

Note) Since the nut and the balls use stainless steel, these models are highly resistant to corrosion and environment.
If oil holes are required, please specify by adding OH to the end of the model number.
For further information, contact THK.

Model LMH-L



Models LMH6L to 13L




Models LMH16L to 30L

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
Standard type									
LMH 6L	4	6	0 −0.010	12	0	35	0 −0.3	28	0 −0.2
LMH 8L	4	8		15	−0.013	45		32	
LMH 10L	4	10		19	0 −0.016	55		39	
LMH 12L	4	12		21		57		42	
LMH 13L	4	13		23		61		43	
LMH 16L	5	16	0 −0.012	28	0 −0.019	70	0 −0.4	48	
LMH 20L	5	20		32		80		54	
LMH 25L	6	25		40		112		62	
LMH 30L	6	30		45		123		74	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMH20L UU

└─── Seal attached on both ends of the nut




Unit: mm


	K	H	B	C	Mounting hole d ₁ × d ₂ × h	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass
						μm	μm	μm	C N	C ₀ N	
	18	5	20	—	3.4 × 6.5 × 3.3	15	15	-5	324	529	27
	21	5	24	—	3.4 × 6.5 × 3.3	15	15	-5	431	784	41
	25	6	29	—	4.5 × 8 × 4.4	15	15	-5	588	1100	72
	27	6	32	—	4.5 × 8 × 4.4	15	15	-5	657	1200	81
	29	6	33	—	4.5 × 8 × 4.4	15	15	-7	814	1570	105
	34	6	31	22	4.5 × 8 × 4.4	15	15	-7	1230	2350	182
	38	8	36	24	5.5 × 9.2 × 5.4	20	20	-9	1400	2750	217
	46	8	40	32	5.5 × 9.2 × 5.4	20	20	-9	1560	3140	477
	51	10	49	35	6.6 × 11 × 6.5	20	20	-9	2490	5490	575

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMH-ML (Stainless Steel Type)



Models LMH 6ML to 13ML




Models LMH 16ML to 30ML

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMH 6ML	4	6	0 -0.010	12	0	35	0 -0.3	28	0 -0.2
LMH 8ML	4	8		15	-0.013	45		32	
LMH 10ML	4	10		19	0 -0.016	55		39	
LMH 12ML	4	12		21		57		42	
LMH 13ML	4	13		23		61		43	
LMH 16ML	5	16	0 -0.012	28	0 -0.019	70	0 -0.4	48	
LMH 20ML	5	20		32		80		54	
LMH 25ML	6	25		40		112		62	
LMH 30ML	6	30		45		123		74	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If an equipped seal is required, please specify when placing an order.

(Example) LMH20ML UU
└── Seal attached on both ends of the nut




Unit: mm

	K	H	B	C	Mounting hole d ₁ × d ₂ × h	Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic load rating		Mass
						μm	μm	μm	C N	C ₀ N	
	18	5	20	—	3.4 × 6.5 × 3.3	15	15	-5	324	529	27
	21	5	24	—	3.4 × 6.5 × 3.3	15	15	-5	431	784	41
	25	6	29	—	4.5 × 8 × 4.4	15	15	-5	588	1100	72
	27	6	32	—	4.5 × 8 × 4.4	15	15	-5	657	1200	81
	29	6	33	—	4.5 × 8 × 4.4	15	15	-7	814	1570	105
	34	6	31	22	4.5 × 8 × 4.4	15	15	-7	1230	2350	182
	38	8	36	24	5.5 × 9.2 × 5.4	20	20	-9	1400	2750	217
	46	8	40	32	5.5 × 9.2 × 5.4	20	20	-9	1560	3140	477
	51	10	49	35	6.6 × 11 × 6.5	20	20	-9	2490	5490	575

Note) Since the nut and the balls use stainless steel, these models are highly resistant to corrosion and environment.
If oil holes are required, please specify by adding OH to the end of the model number.
For further information, contact THK.


Model LMIF




Model LMIF

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMIF 6	4	6	0 -0.009	12	0	19	±0.3	28	0 -0.2
LMIF 8		8		15	-0.011	24		32	
LMIF 10		10		19	0 -0.013	29		39	
LMIF 12		12		21		30		42	
LMIF 13		13		23		32		43	
LMIF 16	5	16	0 -0.010	28	0 -0.016	37		48	
LMIF 20		20		32		42		54	
LMIF 25	6	25		40		59		62	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMIF16 UU

Seal attached on both ends of the nut




Unit: mm

							Flange	Eccentricity (max)	Radial clearance	Basic Load Rating			
Length			D ₂	H	PCD	Mounting hole	perpendicularity		tolerance	C	C ₀	Mass	
	I	Tolerance					μm			μm	μm		N
	5	±0.2	12	5	20	3.4×6×3.3	12	12	-5	206	265	24	
			15		24		12		-5	265	402	34	
6			19	6	29	4.5×7.5×4.4	12		-5	373	549	61	
			21		32		12		-5	412	598	69	
			23		33		12		-7	510	775	81	
			28		38		12		-7	775	1180	125	
			8			32	8	43	5.5×9×5.4	15	15	-9	863
40	51					15		-9		980		1570	305

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMIF-L




Model LMIF-L

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMIF 6L	4	6	0 -0.010	12	0	35	±0.3	28	0 -0.2
LMIF 8L		8		15	-0.013	45		32	
LMIF 10L		10		19	0 -0.016	55		39	
LMIF 12L		12		21		57		42	
LMIF 13L	5	13	0 -0.012	23		61		43	
LMIF 16L		16		28		70		48	
LMIF 20L		20		32	0	80		54	
LMIF 25L	6	25		40	-0.019	112		62	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
 If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMIF16L UU
 Seal attached on both ends of the nut




Unit: mm

						Flange	Eccentricity (max)	Radial clearance	Basic Load Rating			
	Length		D ₂	H	PCD	Mounting hole	perpendicularity		tolerance	C	C ₀	Mass
	I	Tolerance				d ₁ ×d ₂ ×h	μm			μm	μm	
	5	±0.2	12	5	20	3.4×6×3.3	12	12	-5	324	529	30
			15		24		12		-5	431	784	46
19	6		29	4.5×7.5×4.4	12	-5	588		1100	83		
21			32		12	-5	657		1200	95		
23			33		12	-7	814		1570	117		
28			38		12	-7	1230		2350	196		
8	32		8	43	5.5×9×5.4	15	15	-9	1400	2750	244	
	40			51		15		-9	1560	3140	498	

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMCF-L




Model LMCF-L

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMCF 6L	4	6	0 -0.010	12	0	35	±0.3	28	0 -0.2
LMCF 8L		8		15	-0.013	45		32	
LMCF 10L		10		19	0 -0.016	55		39	
LMCF 12L		12		21		57		42	
LMCF 13L		13		23		61		43	
LMCF 16L	5	16	0 -0.012	28	0	70		48	
LMCF 20L		20		32	0	80		54	
LMCF 25L	6	25		40	-0.019	112		62	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMCF16L UU

UU Seal attached on both ends of the nut




Unit: mm

						Flange	Eccentricity	Radial	Basic Load		
Length		D ₂	H	PCD	Mounting hole d ₁ × d ₂ × h	perpendicularity	(max)	clearance	Rating		Mass
I	Tolerance					μm	μm	tolerance	C	C ₀	g
15	±0.2	12	5	20	3.4 × 6 × 3.3	12	12	-5	324	529	30
20		15		24		12		-5	431	784	46
24.5		19		29		12		-5	588	1100	83
25.5		21	6	32	4.5 × 7.5 × 4.4	12		-5	657	1200	95
27.5		23		33		12		-7	814	1570	117
32		28		38		12		-7	1230	2350	196
36		32	8	43	5.5 × 9 × 5.4	15	15	-9	1400	2750	244
52		40		51		15		-9	1560	3140	498

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.


Model LMIK




Model LMIK

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMIK 6	4	6	0 -0.009	12	0	19	±0.3	28	0 -0.2
LMIK 8		8		15	-0.011	24		32	
LMIK 10		10		19	0 -0.013	29		39	
LMIK 12		12		21		30		42	
LMIK 13		13		23		32		43	
LMIK 16	5	16	0 -0.010	28	0 -0.016	37		48	
LMIK 20		20		32		42		54	
LMIK 25	6	25		40		59		62	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMIK16 UU

Seal attached on both ends of the nut




Unit: mm

							Flange	Eccentricity (max)	Radial clearance tolerance	Basic Load Rating		Mass	
	Length		D ₂	H	K	PCD	Mounting hole			perpendicularity	C		C ₀
	I	Tolerance										d _r ×d ₂ ×h	μm
5	±0.2		12	5	22	20	3.4×6×3.3	12	12	-5	206	265	18
			15		25	24		12		-5	265	402	27
6			19	6	30	29	4.5×7.5×4.4	12		-5	373	549	46
			21		32	32		12		-5	412	598	52
			23		34	33		12		-7	510	775	65
			28		37	38		12		-7	775	1180	104
8			32	8	42	43	5.5×9×5.4	15	15	-9	863	1370	131
			40		50	51		15		-9	980	1570	267

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMIK-L




Model LMIK-L

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMIK 6L	4	6	0 -0.010	12	0	35	±0.3	28	0 -0.2
LMIK 8L		8		15	-0.013	45		32	
LMIK 10L		10		19	0 -0.016	55		39	
LMIK 12L		12		21		57		42	
LMIK 13L		13		23		61		43	
LMIK 16L	5	16	0 -0.012	28	0 -0.019	70		48	
LMIK 20L		20		32		80		54	
LMIK 25L	6	25		40		112		62	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMIK16L UU

Seal attached on both ends of the nut




Unit: mm

								Flange	Eccentricity	Radial	Basic Load			
Length		D ₂	H	K	PCD	Mounting hole	perpendicularity	(max)	tolerance	C	C ₀	Mass		
I	Tolerance									N	N		g	
5	±0.2	12	5	22	20	3.4×6×3.3	12	12	−5	324	529	25		
		15		25	24		12		−5	431	784	39		
6		19	6	30	29	4.5×7.5×4.4			12	−5	588	1100	69	
		21		32	32				12	−5	657	1200	78	
		23		34	33				12	−7	814	1570	101	
		28		37	38				12	−7	1230	2350	174	
8		32	8	42	43	5.5×9×5.4		15	15	−9	1400	2750	210	
		40		50	51			15		−9	1560	3140	461	

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMCK-L




Model LMCK-L

Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMCK 6L	4	6	0 -0.010	12	0	35	±0.3	28	0 -0.2
LMCK 8L		8		15	-0.013	45		32	
LMCK 10L		10		19	0 -0.016	55		39	
LMCK 12L		12		21		57		42	
LMCK 13L		13		23		61		43	
LMCK 16L	5	16	0 -0.012	28	0	70		48	
LMCK 20L		20		32	0	80		54	
LMCK 25L	6	25		40	-0.019	112		62	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
 If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMCK16L UU
 _____ Seal attached on both ends of the nut




Unit: mm

							Flange	Eccentricity	Radial	Basic Load		
Length						Mounting hole	perpendicularity	(max)	clearance	Rating		Mass
I	Tolerance	D ₂	H	K	PCD	d ₁ × d ₂ × h	μm	μm	tolerance	C	C ₀	g
15	±0.2	12	5	22	20	3.4 × 6 × 3.3	12	12	-5	324	529	25
20		15		25	24		12		-5	431	784	39
24.5		19		30	29		12		-5	588	1100	69
25.5		21	6	32	32	4.5 × 7.5 × 4.4	12		-5	657	1200	78
27.5		23		34	33		12		-7	814	1570	101
32		28		37	38		12		-7	1230	2350	174
36		32	8	42	43	5.5 × 9 × 5.4	15	15	-9	1400	2750	210
52		40		50	51		15		-9	1560	3140	461

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMIH




Model LMIH


Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMIH 6	4	6	0 -0.009	12	0	19	±0.3	28	0 -0.2
LMIH 8		8		15	-0.011	24		32	
LMIH 10		10		19	0 -0.013	29		39	
LMIH 12		12		21		30		42	
LMIH 13		13		23		32		43	
LMIH 16	5	16	0 -0.010	28	0 -0.016	37	±0.3	48	0 -0.2
LMIH 20		20		32		42		54	
LMIH 25	6	25	-0.010	40	-0.016	59	±0.3	62	-0.2

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMIH16 UU
_____ Seal attached on both ends of the nut



Models LMIH 6 to 13




Models LMIH 16 to 25

Unit: mm

									Flange	Eccentricity (max)	Radial clearance	Basic Load Rating		
	Length							Mounting hole	perpendicularity		tolerance	C	C ₀	Mass
	I	Tolerance	D ₂	H	K	B	C	d ₁ ×d ₂ ×h	μm	μm	μm	N	N	g
	5	±0.2	12	5	18	20	—	3.4×6×3.3	12	12	—5	206	265	20
			15		21	24	—		12		—5	265	402	29
6	19		6	25	29	—	4.5×7.5×4.4	12	—5		373	549	50	
	21			27	32	—		12	—5		412	598	57	
	23			29	33	—		12	—7		510	775	70	
	28			34	31	22		12	—7		775	1180	111	
8	32		8	38	36	24	5.5×9×5.4	15	15	—9	863	1370	140	
	40			46	40	32		15		—9	980	1570	276	

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMIH-L




Model LMIH-L


Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
LMIH 6L	4	6	0 -0.010	12	0	35	± 0.3	28	0 -0.2
LMIH 8L		8		15	-0.013	45		32	
LMIH 10L		10		19	0 -0.016	55		39	
LMIH 12L		12		21		57		42	
LMIH 13L		13		23		61		43	
LMIH 16L	5	16	0 -0.012	28	0 -0.019	70		48	
LMIH 20L		20		32		80		54	
LMIH 25L	6	25		40		112		62	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMIH16L UU
└── Seal attached on both ends of the nut



Models LMIH 6L to 13L




Models LMIH 16L to 25L

Unit: mm

								Flange	Eccentricity (max)	Radial clearance	Basic Load Rating			
	Length							perpendicularity		tolerance	C	C ₀	Mass	
	I	Tolerance	D ₂	H	K	B	C	d ₁ ×d ₂ ×h	μm	μm	μm	N	N	g
	5	±0.2	12	5	18	20	—	3.4×6×3.3	12	12	—5	324	529	26
			15		21	24	—		12		—5	431	784	41
6	19		6	25	29	—	4.5×7.5×4.4	12	—5		588	1100	73	
	21			27	32	—		12	—5		657	1200	83	
	23			29	33	—		12	—7		814	1570	106	
	28			34	31	22		12	—7		1230	2350	180	
8	32		8	38	36	24	5.5×9×5.4	15	15	—9	1400	2750	219	
	40			46	40	32		15		—9	1560	3140	470	

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model LMCH-L




Model LMCH-L


Model No.	Ball rows	Main dimensions							
		Inscribed bore diameter		Outer diameter		Overall length		Flange diameter	
		dr	Tolerance	D	Tolerance	L	Tolerance	D ₁	Tolerance
Standard Type									
LMCH 6L	4	6	0 -0.010	12	0	35	±0.3	28	0 -0.2
LMCH 8L		8		15	-0.013	45		32	
LMCH 10L		10		19	0 -0.016	55		39	
LMCH 12L		12		21		57		42	
LMCH 13L		13		23		61		43	
LMCH 16L	5	16	0 -0.012	28	0	70		48	
LMCH 20L		20		32	0	80		54	
LMCH 25L	6	25		40	-0.019	112		62	

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
 If requiring a type equipped with a seal, indicate it when placing an order.

(Example) LMCH16L UU
 Seal attached on both ends of the nut



Models LMCH 6L to 13L




Models LMCH 16L to 25L

Unit: mm

										Flange perpendicularity	Eccentricity (max)	Radial clearance tolerance	Basic Load Rating		Mass
Length		D ₂	H	K	B	C	Mounting hole d ₁ × d ₂ × h			μm	μm	μm	C	C ₀	g
I	Tolerance												N	N	
15	±0.2	12	5	18	20	—	3.4 × 6 × 3.3			12	12	-5	324	529	26
20		15		21	24	—				12		-5	431	784	41
24.5		19		25	29	—	4.5 × 7.5 × 4.4			12		-5	588	1100	73
25.5		21	6	27	32	—				12		-5	657	1200	83
27.5		23		29	33	—				12		-7	814	1570	106
32		28		34	31	22				12		-7	1230	2350	180
36		32	8	38	36	24	5.5 × 9 × 5.4			15	15	-9	1400	2750	219
52		40		46	40	32				15		-9	1560	3140	470

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Models SC6 to 30




Model No.	Outer dimensions			LM casing dimensions						
	Height	Width	Length	Mounting hole position			Tap	Through bolt	Center height	W_1 ± 0.02
	M	W	L	B	B_1	C	$S \times l$	model No, S_2	J ± 0.02	
SC 6UU	18	30	25	20	5	15	M4×8	M3	9	15
SC 8UU	22	34	30	24	5	18	M4×8	M3	11	17
SC 10UU	26	40	35	28	6	21	M5×12	M4	13	20
SC 12UU	29	42	36	30.5	5.75	26	M5×12	M4	15	21
SC 13UU	30	44	39	33	5.5	26	M5×12	M4	15	22
SC 16UU	38.5	50	44	36	7	34	M5×12	M4	19	25
SC 20UU	42	54	50	40	7	40	M6×12	M5	21	27
SC 25UU	51.5	76	67	54	11	50	M8×18	M6	26	38
SC 30UU	59.5	78	72	58	10	58	M8×18	M6	30	39

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
 A stainless steel Linear Bushing model LM-MG, which is highly corrosion resistant, can also be incorporated at your request.

Example of Model Number for Use in Combination with
 Linear Bushing Units

Linear Bushing to be combined	Examble of model No.	
Both end attached with seal	SC 13UU	Standard stock
Without seal	SC 13	Build to order
Made of stainless steel; both end attached with seal	SC 13MUU	Build to order




Unit: mm

							Model No. of Linear Bushing to be combined	Basic load rating		Unit
						Inscribed bore diameter		C	C ₀	Mass
	K	W ₂	T	R	dr	Tolerance		N	N	g
	15	28	6	9	6	0 -0.009	LM6UU	206	265	34
	18	32	6	11	8		LM8UU	265	402	52
	22	37	8	13	10		LM10UU	373	549	92
	25	39	8	14	12		LM12UU	412	598	102
	26	41	8	15	13		LM13UU	510	775	123
	35	46	9	19.5	16		LM16UU	775	1180	189
	36	52	11	21	20	0 -0.010	LM20UU	863	1370	237
	41	68	12	25.5	25		LM25UU	980	1570	555
	49	72	15	29.5	30		LM30UU	1570	2750	685

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Models SC35 to 50





Models SC35 to 50

Model No.	Outer dimensions			LM casing dimensions							
	Height	Width	Length	Mounting hole position			Tap	Through bolt	Center height		
	M	W	L	B	B ₁	C	S \times ℓ	model No, S ₂	J ± 0.02	W ₁ ± 0.02	K
SC 35UU	68	90	80	70	10	60	M8 \times 18	M6	34	45	54
SC 40UU	78	102	90	80	11	60	M10 \times 25	M8	40	51	62
SC 50UU	102	122	110	100	11	80	M10 \times 25	M8	52	61	80


Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80°C.
A stainless steel Linear Bushing model LM-MG, which is highly corrosion resistant, can also be incorporated at your request.
(Model SC50 does not include a stainless type.)

Example of Model Number for Use in Combination with Linear Bushing Units

Linear Bushing to be combined	Example of model No.	
Both end attached with seal	SC 40UU	Standard stock
Without seal	SC 40	Build to order
Made of stainless steel; both end attached with seal	SC 40MUU	Build to order



A arrow view Model SC35




A arrow view Model SC40 and SC60

Unit: mm

									Model No. of Linear Bushing to be combined	Basic load rating		Unit
	W ₂	W ₃	L ₁	T	R	R ₁	Inscribed bore diameter			C	C ₀	Mass
							dr	Tolerance		N	N	
	85	60	42	18	34	5	35	0 -0.012	LM35UU	1670	3140	1100
	96	80	44	20	38	8	40		LM40UU	2160	4020	1600
	116	100	64	25	50	8	50		LM50UU	3820	7940	3350

Note) If an oil hole is required, this can be indicated by appending "OH" to the end of the model number.
For further information, contact THK.

Model SL




Model SL

Model No.	Outer dimensions			LM casing dimensions						
	Height	Width	Length	Mounting hole position			Tap	Through bolt	Center height	W ₁ ±0.02
	M	W	L	B	B ₁	C	S×ℓ	model No, S ₂	J ±0.02	
SL 6UU	18	30	48	20	5	36	M4×8	M3	9	15
SL 8UU	22	34	58	24	5	42	M4×8	M3	11	17
SL 10UU	26	40	68	28	6	46	M5×12	M4	13	20
SL 12UU	29	42	70	30.5	5.75	50	M5×12	M4	15	21
SL 13UU	30	44	75	33	5.5	50	M5×12	M4	15	22
SL 16UU	38.5	50	85	36	7	60	M5×12	M4	19	25
SL 20UU	42	54	96	40	7	70	M6×12	M5	21	27
SL 25UU	51.5	76	130	54	11	100	M8×18	M6	26	38
SL 30UU	59.5	78	140	58	10	110	M8×18	M6	30	39

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80℃.
 A stainless steel Linear Bushing model LM-MG, which is highly corrosion resistant, can also be incorporated at your request.

Example of Model Number for Use in Combination with Linear Bushing Units


Linear Bushing to be combined	Example of model No.	
Both end attached with seal	SL 13UU	Standard stock
Without seal	SL 13	Build to order
Made of stainless steel; both end attached with seal	SL 13MUU	Build to order



Unit: mm

								Model No. of Linear Bushing to be combined	Basic load rating		Unit
									C	C ₀	Mass
											N
	K	W ₂	T	R	N	Inscribed bore diameter					
						dr	Tolerance				
	15	28	6	9	7	6	0 -0.009	LM6U	324	529	68
	18	32	6	11	7	8		LM8U	431	784	105
	22	37	8	13	7	10		LM10U	588	1100	185
	25	39	8	14	6.5	12		LM12U	657	1200	205
	26	41	8	15	6.5	13		LM13U	814	1570	242
	35	46	9	19.5	6	16		LM16U	1230	2350	403
	36	52	11	21	7	20	0 -0.010	LM20U	1400	2750	520
	41	68	12	25.5	4	25		LM25U	1560	3140	1120
	49	72	15	29.5	5	30		LM30U	2490	5490	1440

Model SH





Model SH

Model No.	Outer dimensions			LM casing dimensions					
	Height	Width	Length	Mounting hole position			Tap		Through bolt
	M	W	L	B	B ₁	C	S ₁ × l ₁	S ₂ × l	model No, S ₃
SH 3UU	14	10	13	—	8	3	M3 × 6	M3 × 5.5	M2
SH 4UU	16	12	15	—	10	3	M3 × 6	M3 × 6	M2
SH 5UU	18	14	17	—	12	3	M3 × 6	M3 × 6	M2
SH 6UU	22	16	24	18	9	5	M4 × 8	M4 × 8	M3
SH 8UU	26	20	27	20	10	5	M4 × 8	M5 × 8.5	M3
SH 10UU	32	26	35	27	15	6	M5 × 10	M6 × 9.5	M4
SH 12UU	34	28	35	27	15	6	M5 × 10	M6 × 9.5	M4
SH 13UU	36	30	36	28	16	6	M5 × 10	M6 × 9.5	M4
SH 16UU	42	36	40	32	18	6	M5 × 10	M6 × 10	M4
SH 20UU	49	42	44	36	22	7	M6 × 12	M6 × 12	M5


Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80℃.
 A stainless steel Linear Bushing model LM-MG, which is highly corrosion resistant, can also be incorporated at your request.

Example of Model Number for Use in Combination with Linear Bushing Units

Linear Bushing to be combined	Example of model No.	
Both end attached with seal	SH 13UU	Standard stock
Without seal	SH 13	Build to order
Made of stainless steel; both end attached with seal	SH 13MUU	Build to order



Top surface of models SH6 to SH20




Top surface of models SH3 to SH5

Unit: mm

							Model No. of Linear Bushing to be combined	Basic load rating		Unit
Center height J ±0.02	W _i ±0.02	d ₂	h	Inscribed bore diameter		C N		C ₀ N	Mass g	
				dr	Tolerance					
	9	5	4.2	1.5	3	0 -0.008	LM3UU	88.2	108	4.5
	10	6	4.2	1.5	4		LM4UU	88.2	127	7
	11	7	4.2	1.5	5		LM5UU	167	206	11
	14	8	6.5	3.3	6		LM6UU	206	265	21
	16	10	6.5	3.3	8	0 -0.009	LM8UU	265	402	34
	19	13	8	4.4	10		LM10UU	373	549	67
	20	14	8	4.4	12		LM12UU	412	598	74
	21	15	8	4.4	13		LM13UU	510	775	91
	24	18	8	4.4	16		LM16UU	775	1180	157
	28	21	9.5	5.4	20	0 -0.010	LM20UU	863	1370	206

Model SH-L




Model SH-L

Model No.	Outer dimensions			LM casing dimensions					
	Height	Width	Length	Mounting hole position			Tap		Through bolt
	M	W	L	B	B ₁	C	S ₁ × ℓ_1	S ₂ × ℓ	model No, S ₃
SH 3LUU	14	10	23	10	18	3	M3 × 6	M3 × 5.5	M2
SH 4LUU	16	12	27	14	22	3	M3 × 6	M3 × 6	M2
SH 5LUU	18	14	32	18	26	3	M3 × 6	M3 × 6	M2
SH 6LUU	22	16	40	20	30	5	M4 × 8	M4 × 8	M3
SH 8LUU	26	20	52	30	42	5	M4 × 8	M5 × 8.5	M3
SH 10LUU	32	26	60	36	50	6	M5 × 10	M6 × 9.5	M4
SH 12LUU	34	28	62	36	50	6	M5 × 10	M6 × 9.5	M4
SH 13LUU	36	30	66	40	54	6	M5 × 10	M6 × 9.5	M4
SH 16LUU	42	36	76	52	66	6	M5 × 10	M6 × 10	M4
SH 20LUU	49	42	86	58	72	7	M6 × 12	M6 × 12	M5

Note) Since this model contains a synthetic resin retainer, do not use it at temperature exceeding 80℃.
 A stainless steel Linear Bushing model LM-MG, which is highly corrosion resistant, can also be incorporated at your request.

Example of Model Number for Use in Combination with Linear Bushing Units


Linear Bushing to be combined	Example of model No.	
Both end attached with seal	SH 13LUU	Standard stock
Without seal	SH 13L	Build to order
Made of stainless steel; both end attached with seal	SH 13MLUU	Build to order



Unit: mm

							Model No. of Linear Bushing to be combined	Basic load rating		Unit
Center height J ±0.02	W _i ±0.02	d ₂	h	Inscribed bore diameter		C		C ₀	Mass	
				dr	Tolerance				N	N
	9	5	4.2	1.5	3	0 -0.008	LM3U	139	216	8.6
	10	6	4.2	1.5	4		LM4U	139	254	14
	11	7	4.2	1.5	5		LM5U	263	412	22
	14	8	6.5	3.3	6	0 -0.009	LM6U	324	529	37
	16	10	6.5	3.3	8		LM8U	431	784	68
	19	13	8	4.4	10		LM10U	588	1100	125
	20	14	8	4.4	12		LM12U	657	1200	140
	21	15	8	4.4	13		LM13U	814	1570	176
	24	18	8	4.4	16		LM16U	1230	2350	309
	28	21	9.5	5.4	20	0 -0.010	LM20U	1400	2750	413

Model SK



Unit: mm

Model No.	Main dimensions													Mass
	H	W	L	B	S	Mounting bolt model No.	h ±0.02	A ±0.05	b	g	l	Shaft diameter d	Tightening bolt model No.	
SK 10	32.8	42	14	32	5.5	M5	20	21	5	6	18	10	M4	24
SK 12	37.5	42	14	32	5.5	M5	23	21	5	6	20	12	M4	30
SK 13	37.5	42	14	32	5.5	M5	23	21	5	6	20	13	M4	30
SK 16	44	48	16	38	5.5	M5	27	24	5	8	25	16	M4	40
SK 20	51	60	20	45	6.6	M6	31	30	7.5	10	30	20	M5	70
SK 25	60	70	24	56	6.6	M6	35	35	7	12	38	25	M6	130
SK 30	70	84	28	64	9	M8	42	42	10	12	44	30	M6	180
SK 35	83	98	32	74	11	M10	50	49	12	15	50	35	M8	270
SK 40	96	114	36	90	11	M10	60	57	12	15	60	40	M8	420

Standard LM Shafts

THK manufactures high quality, dedicated LM shafts for linear bushings.

(1) [Major materials]

SUJ2 (high-carbon chromium bearing steel)

THK5SP (THK standard material)

SUS440C equivalent

[Hardness] 58 to 64 HRC (SUJ2, THK5SP), 56 HRC or above (SUS440C or equivalent)

[Hardened layer depth] 0.8 to 2.5 mm (varies with shaft diameter)

[Surface roughness] Ra 0.4 or less

[Straightness of the LM shaft] 50 μ m/300 mm or less

(2) Precision-grade LM shafts with shaft diameter tolerance of g5 or h5 are also manufactured as standard.



Unit: mm


Model No.	Shaft diameter		Manufactured length L	
	d	Tolerance g6 μ m	Min length	Max length
SF 3	3	-2 -8	20	400
SF 4	4	-4 -12	20	400
SF 5	5		20	500
SF 6	6		20	1500
SF 8	8	-5 -14	20	1500
SF 10	10		30	1500
SF 12	12	-6 -17	30	1500
SF 13	13		30	1500
SF 16	16	-7 -20	40	3000
SF 20	20		40	3000
SF 25	25		50	3000
SF 30	30		60	3000
SF 35	35	-9 -25	70	3000
SF 38*	38		100	3000
SF 40	40		100	3000
SF 50	50		100	3000
SF 60*	60	-10 -29	200	3000
SF 80*	80		200	3000
SF 100*	100	-12 -34	200	3000

Note)*Made to order

Dimensions of Hollow LM Shafts

If a hollow LM shaft is required for purposes such as weight reduction, use the desired material from Table1 for the dimensions of hollow LM shafts that THK keeps in stock.

Table1 Dimensions of Hollow LM Shafts Unit: mm



Supported model numbers	LM shaft outer diameter d	Inner diameter (φ d₁)	Mass (kg/m)	
			Solid shaft	Hollow shaft
LM 8	8	3	0.4	0.34
LM 10	10	4	0.62	0.52
LM 12	12	6	0.89	0.67
LM 13	13	7	1.05	0.75
LM 16	16	9	1.59	1.09
LM 20	20	10	2.47	1.86
LM 20	20	14	2.47	1.26
LM 25	25	15	3.86	2.47
LM 30	30	16	5.56	3.98
LM 35	35	20	7.57	5.1
* LM 38	38	22	8.92	5.93
LM 40	40	22	9.88	6.89
LM 50	50	25	15.5	11.6
LM 60	60	32	22.3	16.0
* LM 80	80	52.5	39.6	22.5
* LM 100	100	67.5	61.8	33.7

Models marked with “*” are build-to-order items.

Model number coding

SF25 g6 -500L K

Model number

LM shaft outer diameter tolerance

Overall LM shaft length (in mm)

Special symbol*

no symbol: solid shaft K: standard hollow shaft
M: special material F: with surface treatment

*If two or more symbols are given, they are shown in an alphabetical order.

Specially Machined Types

THK also supports special machining processes such as tapping, milling, threading, through hole and end journals, as shown in the Fig.1 , at your request.




Fig.1

Dedicated Shafts

As the dedicated shafts for linear bushings come into direct contact with the ball bearings, the manufacturing tolerances for hardness, surface roughness, and the dimensional precision of the shaft are tight.

When manufacturing dedicated shafts, the surface hardness of the shaft will have a large impact on the overall service life. Check the following material and heat treatment specifications.

Material

Generally, the following materials are used for surface hardening through induction-hardening.

- SUJ2 (JIS G 4805: high-carbon chromium bearing steel)
- SK3 to 6 (JIS G 4401: carbon tool steel)
- S55C (JIS G 4051: carbon steel for machine structural use)

For special applications, martensite stainless steel SUS440C, which is corrosion resistant, may also be used.

Hardness

We recommend surface hardness of 58 HRC (≈ 653 HV) or higher. The depth of the hardened layer is determined by the size of the Linear Bushing; we recommend approximately 2 mm for general use.

Surface Roughness

To achieve smooth motion, the surface should preferably be finished to Ra0.40 or less.

Table of Rows of Balls and Masses for Clearance-adjustable Types and Open Types of the Linear Bushing

Shaft diameter	Clearance-adjustable Type			Open Type		
	Model No.	Rows of balls	Mass g	Model No.	Rows of balls	Mass g
6	LM 6-AJ	4	7.8	—	—	—
8	LM 8S-AJ	4	10	—	—	—
	LM 8-AJ	4	14.7	—	—	—
10	LM 10-AJ	4	29	—	—	—
12	LM 12-AJ	4	31	—	—	—
13	LM 13-AJ	4	42	LM 13-OP	3	34
16	LM 16-AJ	5(4)	68	LM 16-OP	4(3)	52
20	LM 20-AJ	5	85	LM 20-OP	4	69
25	LM 25-AJ	6(5)	216	LM 25-OP	5(4)	188
30	LM 30-AJ	6	245	LM 30-OP	5	210
35	LM 35-AJ	6	384	LM 35-OP	5	350
38	LM 38-AJ	6	475	LM 38-OP	5	400
40	LM 40-AJ	6	579	LM 40-OP	5	500
50	LM 50-AJ	6	1560	LM 50-OP	5	1340
60	LM 60-AJ	6	1820	LM 60-OP	5	1650
80	LM 80-AJ	6	4320	LM 80-OP	5	3750
100	LM 100-AJ	6	8540	LM 100-OP	5	7200
120	LM 120-AJ	8	14900	LM 120-OP	6	11600

Note) The numbers of ball rows in the table apply to types using a resin retainer. Those of types using a metal retainer are indicated in parentheses.


Assembling the Linear Bushing

Inner Diameter of the Housing

Table1 shows recommended housing inner-diameter tolerance for the Linear Bushing. When fitting the Linear Bushing with the housing, loose fit is normally recommended. If the clearance needs to be smaller, provide transition fit.

Table1 Housing Inner-diameter Tolerance

Type		Housing	
Model No.	Accuracy	Loose fit	Transition fit
LM	High accuracy grade (no symbol)	H7	J7
	Precision Grade (P)	H6	J6
LME	—	H7	K6, J6
LMF	High accuracy grade (no symbol)	H7	J7
LMK			
LMH			
LM-L			
LMF-L			
LMK-L			
LMH-L			
LMIF			
LMIK			
LMIH			
LMIF-L			
LMIK-L			
LMIH-L			
LMCF-L			
LMCK-L			
LMCH-L			



[Clearance between the Nut and the LM Shaft]

When using the Linear Bushing in combination with an LM shaft, use normal clearance in ordinary use and small gap if the clearance is to be minimized.

Note1) If the clearance after installation is to be negative, it is preferable not to exceed the radial clearance tolerance indicated in the specification table.

Note2) The shaft tolerance for Linear Bushing models SC, SL SH and SH-L falls under high accuracy grade (no symbol).

Table2 Shaft Outer-diameter Tolerance

Type		LM Shaft	
Model No.	Accuracy	Normal clearance	Small gap
LM	High accuracy grade (no symbol)	f6, g6	h6
	Precision Grade (P)	f5, g5	h5
LME	—	h7	k6
LMF	High accuracy grade (no symbol)	f6, g6	h6
LMK			
LMH			
LM-L			
LMF-L			
LMK-L			
LMH-L			
LMIF			
LMIK			
LMIH			
LMIF-L			
LMIK-L			
LMIH-L			
LMCF-L			
LMCK-L			
LMCH-L			

[Mounting the Nut]

Although the Linear Bushing does not require a large amount of strength for securing it in the axial direction, do not rely only on a press fit to support the nut. For the housing inner-diameter tolerance, see Table1 on A4-112.

● **Mounting a Standard Linear Bushing**

Example mountings are shown in Fig. 1 and Fig. 2. Use snap rings or stopper plates to secure linear bushings.

Securing the nut by pressing against the outer surface with one set screw as shown in Fig. 3 will cause the nut to be deformed.




Fig. 1 Secured by snap ring




Fig. 2 Secured by stopper plate




Fig. 3

■ Snap Ring for Installation

The snap ring types shown in Table 3 can be used for securing the standard Model LM.

Note 1) For models indicated with parentheses, use C-shape concentric snap rings.

Note 2) Table 3 commonly applies to models LM, LM-GA, LM-MG and LM-L.

Table 3 Types of Snap Rings

Model No.	Snap ring			
	For outer surface		For inner surface	
	Needle snap	C-shape snap	Needle snap	C-shape snap
LM 3	—	—	AR 7	—
LM 4	—	—	8	—
LM 5	WR 10	10	10	10
LM 6	12	12	12	12
LM 8	—	15	15	15
LM 8S	—	15	15	15
LM 10	19	19	19	19
LM 12	21	21	21	21
LM 13	23	22	23	—
LM 16	28	—	28	28
LM 20	32	—	32	32
LM 25	40	40	40	40
LM 30	45	45	45	45
LM 35	52	52	52	52
LM 38	—	56·58	57	—
LM 40	—	60	60	60
LM 50	—	80	80	80
LM 60	—	90	90	90
LM 80A	—	120	120	120
LM 100A	—	(150)	150	—
LM 120A	—	(180)	180	—

[Inserting the Nut]

When inserting the standard linear bushing into a housing, do not directly hit the seal or side plate. Use a jig to evenly drive in the nut, or place a flatter piece of metal on the nut and gently hit that. (See Fig. 4)




Fig. 4

● Installing a Clearance-adjustable Type

To adjust the clearance of a clearance-adjustable type (-AJ), use a housing that allows adjustment of the nut outer diameter so as to facilitate the adjustment of the clearance between the Linear Bushing and the LM shaft. Positioning the slit of the Linear Bushing at an angle of 90° with the housing's slit will provide uniform deformation in the circumferential direction. (See Fig.5.)




Fig.5

● Mounting an Open Type

For an open type (-OP), also use a housing that allows adjustment of the nut outer diameter as shown in Fig.6.

Open types are normally used with a light preload. Be sure not to give an excessive preload.




Fig.6

[Precautions on Installing an Open Three-ball-row Type Linear Bushing]

When installing an open three-ball-row type Linear Bushing, mount it while taking into account the load distribution as indicated in Fig.7.






Fig.7

- **Installing the Flanged Type**

With models LMF, LMK, LMH, LMIF, LMCF, LMIK, LMCK, LMIH, and LMCH, the nut is integrated with a flange. Therefore, the linear bushing can be mounted only via the flange.




Mounted via spigot and socket joint




Mounted via flange only

However, the Model LMJK must be mounted via a spigot and socket joint. Please do not mount using just the flange.



Mounted via spigot and socket joint



Mounted via flange only

- **Installing the LM Case Unit**

- **Attaching Model SC (SL)**

Models SC and SL can be affixed from either above or below using bolts. (See Fig. 8)






Fig. 8

- **Attaching the Model SH (SH-L)**

Models SH and SH-L can be affixed in any direction using bolts. (See Fig. 9)



Basic installation




Alternative installations

Fig. 9

[Mounting the Shaft End Support]

Shaft end support model SK can easily be secured to the table using mounting bolts. Model SK enables the LM shaft to firmly be secured using tightening bolts.

**[Inserting the LM Shaft]**

When inserting the LM shaft into the Linear Bushing, align the center of the shaft with that of the nut and gently insert the shaft straightforward into the nut. If the shaft is slanted while it is inserted, balls may fall off or the retainer may be deformed. (See Fig.10 .)




Fig.10

[When Under a Moment Load]

When using the Linear Bushing, make sure the load is evenly distributed on the whole ball raceway. In particular, if a moment load is applied, use two or more Linear Bushing units on the same LM shaft and secure an adequately large distance between the units.

If using the Linear Bushing under a moment load, also calculate the equivalent radial load and identify the correct model number. (See **A4-39** .)

[Rotational Use Not Allowed]

The Linear Bushing is not suitable for rotational use for a structural reason. (See Fig.11.)

Forcibly rotating it may cause an unexpected accident.




Fig.11

[Attaching Felt Seal Model FLM]

The felt seal can be press-fit into a housing finished to H7, but cannot be used as a stopper for preventing the Linear Bushing from coming off. Be sure to use the felt seal by attaching it as indicated in the Fig.12.

Also make sure to impregnate the felt with sufficient lubricant before attaching it.




Fig.12

Lubrication

The Linear Bushing requires grease or oil as a lubricant for its operation.

[Grease Lubrication]

Before mounting the product onto the LM shaft, apply grease to each row of balls inside the Guide Ball Bushing.

Thereafter apply grease as necessary, in accordance with usage and other conditions noted above, or attach housing as shown in Fig. 1, or apply grease directly to the LM shaft.

We recommend using lithium soap-based grease No. 2.

[Oil Lubrication]

Apply the required amount of oil or grease-based lubricant onto the LM shaft and set it in the housing as shown in Fig. 1.

Commonly used lubricants include turbine oil, machine oil, and spindle oil.

In addition to the procedures described the above, an oil hole or grease nipple can also be used for lubrication. For further information, contact THK.




Fig. 1

Material and Surface Treatment

For the Linear Bushing and the LM shaft, highly corrosion-resistant stainless steel types are available for some models.

Although the LM shaft can be surface treated, some types may not be suitable for the treatment. Contact THK for details.

Dust prevention

Entrance of dust or other foreign material into the Linear Bushing will cause abnormal wear or shorten the service life. When entrance of dust or other foreign material is a possibility, it is important to select effective seals and/or a dust-control device that meets the service environment conditions. For the Linear Bushing, a special synthetic rubber seal that is highly resistant to wear and a felt seal (highly dust preventive with low seal resistance) are available as contamination protection accessories. In addition, THK produces round bellows. Contact us for details.


Felt Seal Model FLM

Linear Bushing model LM series include types equipped with a special synthetic rubber seal (LM···UU, U). If desiring to have an additional contamination protection measure, or desiring to lower the seal resistance, use the felt seal model FLM. (See Table1)

Dimensions of the Felt Seal

Table1 Major Dimensions of FLM

Unit: mm



Model No.	Main dimensions				Supported linear bushing model
	d	D	B	H	
FLM 6	6	12	2	2	LM 6
FLM 8	8	15	2	2	LM 8
FLM 10	10	19	3	3	LM 10
FLM 12	12	21	3	3	LM 12
FLM 13	13	23	3	3	LM 13
FLM 16	16	28	4	5	LM 16
FLM 20	20	32	4	5	LM 20
FLM 25	25	40	5	6	LM 25
FLM 30	30	45	5	6	LM 30
FLM 35	35	52	5	6	LM 35
FLM 38	38	57	5	6	LM 38
FLM 40	40	60	5	6	LM 40
FLM 50	50	80	10	11	LM 50
FLM 60	60	90	10	11	LM 60
FLM 80	80	120	10	11	LM 80
FLM 100	100	150	10	11	LM 100

Model Number Coding

Model number configurations differ depending on the model features. Refer to the corresponding sample model number configuration.

Linear Bushing

- LM, LME, LM-L, LMF, LMF-L, LMK, LMK-L, LMJK, LMJK-L, LMH, LMH-L, LMIF, LMIF-L, LMCF-L, LMIK, LMIK-L, LMCK-L, LMIH, LMIH-L, LMCH-L, SC, SL, SH, SH-L

LM20 L UU
 Model No. Long type With nut seal

- LM-M, LM-MG, LMF-M, LMF-ML, LMK-M, LMK-ML, LMH-M, LMH-ML

LMF20 M L UU
 Model No. Made of stainless steel Long type With nut seal

- LM-GA, LM-MGA, LME-GA

LM20 M GA UU
 Model No. Made of stainless steel Metal retainer specification With nut seal

Notes on Ordering

For high temperature applications, seals (symbol: UU) can be attached to both ends of the nut on linear bushes used with metal cages (symbol: A). However, cages without seals are recommended, since the seals are only heat-resistant to a temperature of 80°C.

[LM Shaft End Support]


- Model SK

SK20

Model No.

[LM Shaft]

- Model SF



*If two or more symbols are given, they are shown in an alphabetical order.

*For information shaft diameters, permissible shaft diameter error and standard stock lengths, see **A4-109**.

[Felt Seal]

- Model FLM

FLM 20

Model No.

Handling

- (1) Disassembling each part may cause dust to enter the system or degrade mounting accuracy of parts. Do not disassemble the product.
- (2) Take care not to drop or strike the Linear Bushing. Doing so may cause injury or damage. Giving an impact to it could also cause damage to its function even if the product looks intact.
- (3) When handling the product, wear protective gloves, safety shoes, etc., as necessary to ensure safety.

Precautions on Use

- (1) Prevent foreign material, such as cutting chips or coolant, from entering the product. Failure to do so may cause damage.
- (2) If the product is used in an environment where cutting chips, coolant, corrosive solvents, water, etc., may enter the product, use bellows, covers, etc., to prevent them from entering the product.
- (3) Do not use the product at temperature of 80°C or higher. Exposure to higher temperatures may cause the resin/rubber parts to deform/be damaged.
- (4) If foreign material such as cutting chips adheres to the product, replenish the lubricant after cleaning the product.
- (5) Micro-strokes tend to obstruct oil film to form on the raceway in contact with the rolling element, and may lead to fretting corrosion. Take consideration using grease offering excellent fretting prevention. It is also recommended that a stroke movement corresponding to the length of the outer cylinder be made on a regular basis to make sure oil film is formed between the raceway and rolling element.
- (6) Do not use undue force when fitting parts (pin, key, etc.) to the product. This may generate permanent deformation on the raceway, leading to loss of functionality.
- (7) Insert the shaft straight through the opening. Inserting the shaft at an angle can introduce foreign matter, damage internal components, or cause balls to fall out.
- (8) Using this product with any balls removed may result in premature damage.
- (9) Please contact THK if any balls fall out; do not use the product if any balls are missing.
- (10) If an attached component is insufficiently rigid or mounted incorrectly, the bearing load will be concentrated at one location and performance will decline significantly. Make sure the housing and base are sufficiently rigid, the anchoring bolts are strong enough, and the component is mounted correctly.

Lubrication

- (1) Thoroughly wipe off anti-rust oil and feed lubricant before using the product.
- (2) Do not mix different lubricants. Mixing greases using the same type of thickening agent may still cause adverse interaction between the two greases if they use different additives, etc.
- (3) When using the product in locations exposed to constant vibrations or in special environments such as clean rooms, vacuum and low/high temperature, use the grease appropriate for the specification/environment.
- (4) To lubricate the product, apply lubricant directly to the raceway surface and execute a few preliminary strokes to ensure that the interior is fully lubricated.
- (5) The consistency of grease changes according to the temperature. Take note that the slide resistance of the Linear Bushing also changes as the consistency of grease changes.

- (6) After lubrication, the slide resistance of the Linear Bushing may increase due to the agitation resistance of grease. Be sure to perform a break-in to let the grease spread fully, before operating the machine.
- (7) Excess grease may scatter immediately after lubrication, so wipe off scattered grease as necessary.
- (8) The properties of grease deteriorate and its lubrication performance drops over time, so grease must be checked and added properly according to the use frequency of the machine.
- (9) The greasing interval varies depending on the use condition and service environment. Set the final lubrication interval/amount based on the actual machine.

[Storage]

When storing the Linear Bushing, enclose it in a package designated by THK and store it in a room while avoiding high temperature, low temperature and high humidity.

[Disposal]

Dispose of the product properly as industrial waste.